




STEPP MFG
ASPHALT MAINTENANCE EQUIPMENT




OJK-V

STEPP Oil Jacketed Kettle



OPERATIONS/MAINTENANCE/PARTS MANUAL

LP or Diesel Burner Systems



Stepp Manufacturing Co., Inc.
12325 River Rd
North Branch, MN 55056
Ph: 651-674-4491~ Fax: 651-674-4221
www.steppmfg.com

Warranty

Stepp Manufacturing Company Inc. hereby warrants to the original purchaser that products manufactured by Stepp Mfg will be free from defects in material and workmanship for a period of 1 year from the date of purchase.

Stepp Mfg, at its discretion, will provide for the repair or replacement of any part found upon examination by Stepp Mfg to be defective, except as noted below. Such repair or replacement will be free of charge to the original purchaser for a period of 1 year from the date of purchase, except as noted below.

No warranty is extended to cover:

- Product pump wear or damage caused by foreign object.
- Routine maintenance, cleaning, and adjustments.
- Parts or components that have been altered, misused, improperly adjusted or maintained.
- Transportation to and from the place of warranty repair.
- Removal of material from equipment.

The following items are covered solely by their manufactures warranty:

- Engines
- Hydraulic components
- Burners
- Pumps
- Tires
- Other component parts

The following items are covered by a pro rata warranty:

- Hoses that carry heated materials.
- Heating Elements for hoses and wands.

Disclaimer of further warranty:

Stepp Mfg makes no warranty, expressed or implied, other than this warranty. The implied warranties of merchantability and fitness for particular purpose are hereby disclaimed. Repair or replacement of products or parts proving to be defective in material or workmanship shall be the exclusive remedy for breach of this warranty.

Stepp Mfg shall not be liable for incidental or consequential damages. Including but not limited to, damages for inconvenience, rental or purchase of replacement equipment, for loss of profits, loss of material, or other loss resulting from breach of this warranty.

Stepp Mfg reserves the right to incorporate any changes in design into its products without obligation to make such changes on products previously manufactured.

Please see Warranty section for more details.

Stepp Manufacturing Co., Inc.

12325 River Road

North Branch, MN 5506

P: 651-674-4491

F: 651-674-4221

www.steppmfg.com

OJK– Oil Jacketed Kettle

Thank you for selecting the *Stepp OJK* for your crack sealing operations. We are confident you will be satisfied with the *Stepp Oil Jacketed Kettle (OJK)*. *Stepp Manufacturing* is backed by over 65 years of experience in the design and manufacture of highway maintenance equipment. This experience along with our innovative design and unique features make the *Stepp OJK* the fastest and most efficient kettle available. Continued research and development, along with input from you, the user, help make this possible. This manual will make reference to components and systems that may not be installed on your equipment. Many of these are available as options and may be retrofitted to your machine. For more information contact Stepp Mfg.

To assure safe operation of this equipment, the operator must read and understand all operating procedures and safety notices contained in this manual. In addition, the operator *must* receive instruction on how to safely operate the *Stepp OJK*. Contact Stepp Manufacturing if any questions arise or if you desire training for additional staff members. Operating instructions, adjustments and periodic maintenance procedures are given so you ... the operator, can keep your unit working like new and expect many years of dependable service from it. Remember ... any machine, regardless of design or type, will perform only in relation to the way it is operated and the maintenance it receives. Read this manual carefully and observe all Warnings and Cautions. If you have any recommendations or comments, please send them attention to: **Stepp Manufacturing Co. Inc., 12325 River Road, North Branch MN. 55056-6225 or call 651-674-4491.**

When ordering parts or making any inquiry about the *Stepp OJK*, be sure to include the model number and serial number found on the data plate attached to the frame.

TABLE OF CONTENTS

IMPORTANT NOTICE!

This manual contains cautions and warnings that alert you to potential safety issues.

WARNING is used to inform you of conditions or operations that could cause serious injury or death.

CAUTION is used to inform you of conditions or operations that could cause damage to the equipment

NOTE is used to provide you with additional information that may be helpful or useful for a particular situation.

Table of Contents

Introduction	3
Contents	5
Warnings, Cautions, Notes	5
Description	7
Operations	15
Maintenance	23
Troubleshooting	43
Replacement Parts	55
NHTSA Reporting Safety Defects	72
Warranty Guide	73
Watlow Programming	81
Schematics	91
Heat Transfer Oil MSDS	99
Hydraulic Oil MSDS	109
Tire Information/ Engine Manual	Inserts

This manual explains the basic operations, maintenance and use of the Stepp OJK, Oil Jacketed Kettle. The main objective of this equipment is to melt rubberized crack sealing and water proofing compound and apply them to road surfaces.


DESCRIPTION

DESCRIPTION

The *OJK* uses a tank surrounded by an oil jacket filled with heat transfer oil. The heat transfer oil is heated by a diesel fired burner and is circulated in the oil jacket by a pump. In addition to the oil jacket there is a coil surrounding the agitating auger in the tank. Heat transfer oil is pumped through this coil to facilitate heating of the asphalt material. The temperature of the product and the heat transfer oil is automatically maintained by electronic temperature controls.


The heated asphalt is applied to the crack by an electrically heated hose and wand. The heating element in the hose and wand keep the product at working temperature thus eliminating wand "freeze up". No clean-up or flushing of the wand & hose is required.

Power is supplied by a diesel engine. The engine drives a 24 volt alternator for the heated hose and wand. It also drives a hydraulic pump that powers the heat transfer oil circulation pump, product pump, and the agitating auger.



Component Location


1. Safety loading chute — Provides a "splash free" way of loading product into a "hot" tank.
2. Hood — Provides easy access to the inside of the tank for cleaning or "cold" loading.
3. Product pump motor — Powers the pump that pumps the product from the tank to the wand.
4. Expansion tank — Provides room for the heat transfer oil to expand and allows the oil to cool. This creates a "cold seal" effect allowing safer operation at elevated oil temperatures.
5. Hydraulic pump — Provides hydraulic power to the heat transfer oil circulation pump, auger, and the product pump.
6. 24 volt alternator — Provides electrical power to the wand and hose heating elements.
7. Engine control panel — Provides a means of controlling engine functions.
8. Engine fuel filter — Provides clean fuel to engine.
9. Hydraulic filter — Removes contaminants from the hydraulic system.
10. Hydraulic reservoir — Provides a 15 gallon capacity for the hydraulic system.
11. Fuel tank — Stores 30 gallons of diesel fuel to operate the burner and the engine.
12. Heat exchanger chamber — Exchanges heat from the burner to the heat transfer oil.
13. Wand & Hose — Provides a means of applying the product to the road surface.
14. Product pump control — Allows the operator to start, stop, or reverse the rotation and control the speed of the product pump.



DESCRIPTION

Component Location

1. Thermometer — Indicates the temperature of the material as it is pumped from the tank.
2. Wand Pressure Control (WPC) valve — Controls the amount of pressure being applied to the hose & wand when the Pump Saver System is not used. Also allows the operator to divert the flow of material back to tank for circulation, or to the wand for application to the road surface.
3. Drive Motor — Hydraulic drive motor powers the product pump.
4. Circulating Flange — The wand is placed into this port allowing circulation through the wand and back to tank.
5. Wand Rest — Holds the wand in position when circulating through the wand back to tank.
6. Draw off cock — Provides a means of draining tank or filling dispensing equipment.
7. Thermal Well — Contains temperature sensor for product temperature.
8. Heat Transfer Oil Level Plug — Allows easy check of oil level only when unit is cold.
9. Thermostats — Digital display thermostats control the temperature of the heat transfer oil and the product temperature
10. Wand Heat Switch — Supplies power to the electric heated wand & hose.
11. Boom Power Cable — Supplies power for the heating elements in the boom, hose, and wand.



Burner System

The heating system is designed to burn diesel fuel and efficiently heat the transfer oil. The heating system is equipped with constant ignition (flameout protection) and automatic controls to monitor the temperature of the heat transfer oil and the product temperature. Heat transfer oil must be circulated through the heat exchanger when ever the burner is on. This prevents the heat exchanger from over heating and causing damage to the equipment. Operation of the engine is required during the heating cycle to supply hydraulic pressure to the heat transfer oil pump. The pump then circulates the heat transfer oil through the heat exchanger and the hot oil coil in the product tank.

Operation of the burner without the engine running and oil circulating will cause an overheat situation resulting in severe damage to the heat exchanger. Whenever the engine is shut down, the burner is also be shut down.

Temperature Control

The Stepp OJK is equipped with automatic temperature controls. Two thermostats are used to monitor the temperature of the heat transfer oil and the asphalt product. Both thermostats have the capability of shutting off the burner when their respective settings are reached. Continuous observation of the temperature is recommended. If temperatures exceed the thermostat settings, a possible problem with the thermostatic controls may exist. Shut the burner OFF and contact qualified service personnel.

Agitator

This unit is equipped with a hydraulically operated agitator with forward/reverse control. Operating the agitator during the heating cycle will decrease the amount of time and energy necessary to bring the product up to working temperature. The agitator should be turned on as soon as the material melts sufficiently to allow the agitator to rotate. Observe the drive motor for rotation as you engage the lever, if no rotation is observed, allow more heating time to melt the material. The agitator may be run in either direction and left on while applying crack filler. This will give superior performance through even heating of the product.

Product Pump

The *Stepp OJK* is equipped with a hydraulically operated product pump with "Pump & Reverse" control. In the "pump" position, the pump delivers product from the tank, through the hose, and to the wand for application to the road surface. In the "reverse" position the pump draws the product out of the product pump, plumbing, and WPC (wand pressure control) valve to prevent freeze-up when the unit is shut down. The product pump is mounted in the tank allowing it to heat to the proper temperature along with the product, thus it is not necessary to preheat the pump. The product pump should only be engaged when the product has reached a temperature that will allow the product to flow thorough the pump and plumbing.

DESCRIPTION

Wand Pressure Control Valve (WPC Valve)


Operators must understand the proper operation of the WPC valve located on the top rear of the unit. The purpose of this valve is to direct the flow of product either back to the tank (during start-up to assist melting) or to the wand (during crack filling operations).

Because of the properties of rubberized asphalt, no automatic relief valve is installed in the system. Therefore, the operator must adjust the WPC valve to a position midway between the valve stops. This will allow product to flow to the wand and also back to the tank at the same time, preventing excessive pressure from building up in the hose and wand.

Positioning of the WPC valve towards "Re-circulate" will cause less flow and less pressure to the wand. Positioning of the WPC valve towards "Wand" will cause more flow and more pressure to the wand.

The WPC valve should never be positioned fully to the wand position unless the wand control valve located on the wand is fully open, or the optional "Pump Saver" feature is installed and in operation. Excess flow and pressure to the wand may cause damage to the hose and system resulting in personal injury.

Observing unusual flexing in the wand hose should alert the operator that excess pressure is being applied to the wand hose. Considering factors such as temperature of product, desired amount of flow and varied operating conditions will assist the operator in selecting the proper position of the WPC valve. The WPC valve must be left in the re-circulate position when the unit is shut down.



Heated Hose & Wand

The application wand and hose are equipped with an internal heating element. The element is powered by the 24 volt alternator run by the engine. This heating element prevents the product from "freezing" in the hose and wand.

The Electric Wand heat control should be turned on 20 to 30 minutes before trying to pump material through the hose and wand. This will allow time for the material to re-liquefy in the hose.

It is recommended that you circulate the product back to the tank through the wand circulating flange provided in the hood. This is to assure proper flow and temperature of the material going through the wand.

Depending upon the volume of the material going through the wand and the outside temperature, it may not be necessary to run the heated wand all the time. Once flow is established through the wand and circulating back to tank, it is recommended that the electric heating element be used only as required to maintain flow. This will help to extend the service life of the components. If the flow is not adequate to maintain temperature in the hose and wand, freeze up may occur. If this happens, simply turn the electric heating element on and allow time for the material to re-melt.

No clean up is required with the Electric Wand, just shut the machine off as the product can be re-melted by activating the Wand Heat Control. No additional flushing is required.

Overnight Heater (optional)

This feature will maintain the product from 150° to 200° F. thereby saving start up time. The system consists of 2 heating elements submerged in the heat transfer oil.

The heaters require 110V, 15 amp service. The extension cords used must be the outdoor heavy duty type, grounded, and each rated for 1500 watt service.

Engine Controls

The engine controls consist of a starter/glow plug switch, an un-loader switch to relieve the hydraulic pressure for starting purposes, a Murphy switch to stop the engine in case of low oil pressure or high coolant temperatures, and indicator lights for oil pressure, coolant temperature, alternator, and glow plugs. Optional equipment includes an hour meter and engine gauges.

OPERATIONS

Transporting

1. Shut off the burner and the engine.
2. Securely latch the loading chute and re-circulating flange.
3. Secure the wand and hose assembly in the hanger with rubber shock cords or rope.
4. Attach the unit to the towing vehicle being certain hitch is fully engaged, connect safety chains electrical connector, and break away switch (if equipped), retract the landing gear and secure in the up position.
5. Check the condition and operation of the lights, tires, brakes, hitch, and safety chains.

Loading

It is very important that the operator know the operating temperature and flash point of the product being used. This information is available from the product manufacturer. Be sure the thermostat is set at the recommended temperature.

Prior to adding product to the tank, assure the compatibility of the product in the tank to that being loaded. If products are not compatible the tank must be thoroughly drained and cleaned before switching products.

Loading When Cold

1. Release the hood latch.
2. Each side of the hood is equipped with a Lid Breaker to break open the hood if it is stuck.
3. Extend the telescopic handle, tighten the lock, and push down to open the hood.
4. Use the ring to secure in the open position.
5. Load product to the desired level.
6. Close and secure hood.

Loading When Hot

1. Disengage agitator control.
2. Open loading chute and place block of product in chute, close loading chute and product will drop into tank. Open chute and repeat until product is at the desired level.
3. Close loading chute but **DO NOT** latch, this will allow for emergency venting in case of a "flash"
4. Engage agitator control when product is at proper temperature.



Pre Start Checks

The burner system is equipped with a safety interlock that prevents the burner from igniting unless the engine is running.

This safety interlock must be tested each time before the engine is started. Follow the steps below prior to engine start.

1. With engine OFF, turn the burner power switch ON, the burner and blower motor should NOT operate. If the burner or blower motor runs there is a fault in the system, shut OFF burner switch immediately. Contact a qualified service technician and correct the problem before continuing.
2. Be sure the burner switch is in the OFF position.
3. Check the overall appearance of the unit inspecting for any obvious damage.
4. Check all fluid levels, the condition of the hot asphalt hose, and the 24 volt alternator belt. (refer to the daily maintenance schedule)

Engine Starting

Be sure all pre-start checks are complete prior to starting engine.

1. Fill fuel tank.
2. Set the WPC valve to the "re-circulate" position.
3. Set wand heat control to OFF.
4. Set product pump control to neutral (center) position.
5. Set agitator control to neutral (center) position.
6. Turn key counter clockwise to the preheat position until the glow plug indicator light goes out.
7. Hold the un-loader button and the Murphy switch in, then turn the key to the start position, release key when engine starts, then release the Murphy switch.
8. Continue to hold the un-loader button for about 10 seconds to allow the engine to come up to speed, then release the un-loader button.
9. Check to see that the heat transfer oil pump is rotating, if not, investigate problem before proceeding to Heating Operations.



Burner & Pump Operations

1. Start engine (see engine operations).
2. Open burner exhaust rain cap.
3. Unlatch loading chute, this will allow for emergency venting in case of a "flash".
4. Set heating oil thermostat 25 to 50° F above the asphalt product manufacturers recommended temperature.
5. Set product thermostat to the product manufacturers recommended temperature.
6. Turn ON burner power switch and the burner will ignite.
7. When product begins to melt, slowly engage agitator and observe drive motor for rotation, if it does not rotate, allow additional heating time before engaging.
8. If equipped with "Pump Saver" option, set pump saver switch to "re-circulate" position.
9. As the product reaches application temperature, place the WPC valve in the "re-circulate" position and slowly engage product pump hydraulic valve to the "pump" position and observe pump motor for rotation, if no rotation is observed, allow additional heating time. (This will circulate the product with-in the pump and tank.)
10. Place wand into the re-circulating flange and fully open the wand flow control valve located on the wand handle.
11. Set the Electric Wand Heat Control to the ON position and allow 20 to 30 minutes for the elements to heat.
12. Continue to re-circulate the product until the recommended temperature is reached as indicated on the thermometer next to the WPC valve.
13. Slowly move the WPC valve towards the "wand" position to allow the product to flow through the wand and back to the tank. If no product flows out the wand, allow additional time for the electric heating elements to melt the product in the hose and wand.
14. When the product is flowing freely and temperatures are stabilized, the product is ready to apply to the road surface. Proceed to "Application Operations".



Standard Application Operations

Note: If Pump Saver option is installed, refer to Pump Saver Application instructions at bottom of page.

1. Position the WPC valve midway between the wand and re-circulate position.
2. Close the wand flow control valve (located on the wand handle) and remove wand from the re-circulating flange.
3. Set product pump hydraulic control valve to "pump" position, then open the wand flow control valve to apply product to the road surface.
4. Adjust the WPC valve and the pump hydraulic control valve as necessary being careful not to over pressurize the wand and hose assembly.
5. Monitor the level in the tank and add product as necessary.

Application Operations with Optional "Pump Saver"

1. Set Pump Saver switch to "Wand Control" position.
2. Position the WPC valve fully to "wand" position.
3. Close the wand flow control valve (located on the wand handle) and remove wand from the re-circulating flange.
4. Set product pump hydraulic control to "pump" position, then open the wand flow control valve to apply product to the road surface.
5. Adjust the product pump hydraulic control valve as necessary for the desired flow.
6. Monitor the level in the tank and add product as necessary.

CAUTION

Do not engage wand heat unless there is product in the hose.

CAUTION

Positioning of the WPC valve all the way to the "wand" position may cause excess pressure in the wand which may cause damage to the wand hose or system.

The WPC valve should not be positioned fully to the "wand" position unless the wand flow control valve located on the wand is open and product is flowing freely. Or the optional pump saver is in operation.

Observing unusual flexing in the wand hose should signal the operator that excess pressure is being applied to the wand hose and the WPC valve should be adjusted accordingly.

Standard Shut Down Procedures

Note: If Pump Saver option is installed, refer to shut down procedures at bottom of page.

1. Turn OFF the wand heat control switch.
2. Move the WPC valve to the "re-circulate" position.
3. Move the product pump hydraulic control valve to the "reverse" position for 2 minutes, then return lever to the neutral position. This will draw the product out of the pump, plumbing, and WPC valve.
4. Turn both thermostats to their lowest setting.
5. Turn OFF the burner power switch.
6. Place the agitator control lever in the neutral position.
7. Close the rain cap on the exhaust stack.
8. Securely latch all covers

Shut Down Procedure with Optional "Pump Saver"

1. Turn OFF the wand heat control switch.
2. Move the product pump hydraulic control valve to the neutral (center) position.
3. Move the WPC valve to the "re-circulate" position.
4. Set the Pump Saver switch to the "Pump Re-circulate" position.
5. Move the product pump hydraulic control valve to the "reverse" position for 2 minutes, then return lever to the neutral position. This will draw the product out of the pump, plumbing, and WPC valve.
6. Turn both thermostats to their lowest setting.
7. Turn OFF the burner power switch.
8. Place the agitator control lever in the neutral position.
9. Turn key to OFF position to shut down the engine.
10. Close the rain cap on the exhaust stack.
11. Securely latch all covers.

CAUTION

The Stepp OJK requires special shut down procedures that must be followed to maximize safety and equipment performance.

These procedures will assure that the hose and wand always have product in them to avoid an over heated element. (Do Not suck the product back out of the wand and hose assembly)

No hose cleanup is necessary as the product in the hose is re-melted at the next start-up with the wand & hose heating element.

CAUTION

Do not reverse the pump with the WPC valve in the "wand" position as this would suck the product out of the wand and hose assembly. The hose and wand must contain product to absorb the heat from the heating elements to avoid equipment damage. Only reverse the pump when the WPC valve is in the "recirculate" position. No hose cleanup is necessary with this system.

Helpful Hints

1. It is recommended that the product level be drawn down to $\frac{1}{4}$ capacity or less prior to shut down if the machine is not going to be used for 2 or more days. This will decrease the start-up time the next time the machine is used. However, if the equipment will be used the next day leave the unit $\frac{1}{2}$ full or more, then plug in the optional overnight heaters (if available). This will help retain heat for a faster start-up the following day.
2. Over night heating elements normally should not be used for more than 48 hours. Check your product manufacturers specifications for recommended "pot" life.
3. Do not heat or reheat any product for a length of time more than that recommended by the product manufacture. The result of excessive heating time is the material hardens and may be difficult or impossible to remove from the machine.
4. The flow control valve at the end of the wand is not heated by the heating element. Although heat transfer from the wand will normally be enough, by inserting the wand into the re-circulating flange, additional heat from the kettle will aid in heating the valve.
5. If the engine quits for any reason, move the WPC valve to the re-circulate position then attempt to resolve the problem and restart the engine as soon as possible. The proper shut down procedures must be followed before the product hardens in the plumbing between the WPC valve and the top of the kettle. If the product hardens between the WPC valve and the top of the kettle, use heat to re-liquefy the product to reestablish flow.

MAINTENANCE

OJK MAINTENANCE SCHEDULE

ITEM	OPERATION TO PERFORM	HOURS	AS NEEDED	DAILY	EVERY 3MO	EVERY 12 MO	EVERY 24MO
ENGINE	Refer to the engine manufacturers manual insert						
OIL	Check engine oil level, add oil as needed			X			
OIL	Change engine oil and filter.	100					
COOLANT	Check coolant level.			X			
COOLANT	Flush cooling system and replace coolant						X
RADIATOR	Clean radiator fins of dirt and dust with garden hose.		X				
AIR FILTER	Clean air filter		X				
AIR FILTER	Replace air filter	100				X	
FUEL FILTER	Replace fuel filter					X	
FAN BELT	Check condition and tension			X			
HYDRAULICS							
HYD. OIL	Check hydraulic oil level, add oil as necessary			X			
HYD. OIL	Change hydraulic oil.						X
FILTER	Change hydraulic filter.	200				X	
STRAINER	Clean strainer screen					X	
DRIVE LINE							
ALT. BELTS	Check condition and tension of 24v alternator belts			X			
STUB SHAFT	Check stub shaft on engine for wear, looseness, and damage					X	
COUPLING	Check drive line coupling for proper alignment and excess wear.					X	

OJK MAINTENANCE SCHEDULE

ITEM	OPERATION TO PERFORM	HOURS	AS NEEDED	DAILY	EVERY 3MO	EVERY 12 MO	EVERY 24MO
BURNER							
ELECTRODES	Check electrodes for wear and proper adjustment.					X	
BRUSHES	Check brushes for excess wear	300			X		
NOZZLE	Replace fuel nozzle with same size and style					X	
FILTER	Replace burner fuel filter	400				X	
F-HEAD	Check condition of F-head on burner					X	
CONTROLS							
THERMOSTAT	Check that index marks are aligned on knobs for proper calibration			X			
HOT PUMP							
CLEARANCE	Check and adjust end clearances of heat transfer oil pump.						X
PACKING	Adjust shaft seal packing of heat transfer oil pump.		X				
COUPLING	Check pump to hyd. Motor coupling for proper alignment and excess wear.					X	
PRODUCT PUMP							
CLEARANCE	Adjust end clearances of product pump.		X				
PACKING	Adjust shaft seal packing of pump.		X				
COUPLING	Check pump to hyd. Motor coupling for proper alignment and excess wear.					X	
HEAT TRANSFER OIL							
OIL	Check heat transfer oil level.			X			
OIL	Change heat transfer oil.						X

Engine Maintenance

Oil & Filter Change

1. Run engine until operating temperature is reached, then shut OFF engine.
2. Place drain pan under oil drain hose.
3. Open oil drain valve and drain oil from the engine.
4. Close the oil drain valve.
5. Place drain pan under engine oil filter and remove filter.
6. Coat gasket of new oil filter with engine oil and install, hand tighten only.
7. Add 5 quarts SAE 10 W 40 oil.
8. Run engine and check for leaks.
9. Return used oil to a recycling center.

Air Cleaner Service

1. Remove wing nut in center of air cleaner.
2. Remove filter.
3. Clean element following instructions on air cleaner housing. Element may be cleaned up to 6 times before replacement.
4. Reinstall element in housing and tighten wing nut.

Fuel Filter Change

1. Position drain pan under fuel filter.
2. Remove fuel filter.
3. Fill new filter with clean diesel fuel.
4. Lubricate gasket with fuel and install filter, hand tighten.
5. Loosen the air vent plug on the injection pump where the fuel line is attached.
6. Pump the lever on the fuel pump until no air bubbles are present, tighten air vent plug.

Cooling System Service

1. Allow engine to cool to ambient temperature.
2. Open radiator petcock and drain coolant into a suitable container.
3. Open petcock on left side of engine block and drain into a suitable container.
4. Open radiator cap and remove lower radiator hose.
5. Flush clean water through radiator until the water comes out clear.
6. Remove the thermostat then flush clean water through the engine block until the water comes out clear.
7. Install new thermostat and gasket.
8. Install radiator hose and close all petcocks.
9. Refill system with fresh anti freeze in a 50/50 mix.
10. Run engine and check for leaks, then recheck coolant level after engine has cooled.

Hydraulic System Maintenance

Filter Change

1. Position drain pan under filter.
2. Remove oil filter.
3. Lubricate gasket of new filter with hydraulic oil.
4. Install new filter, hand tighten.
5. Start unit and check for leaks.
6. Shut down unit then check hydraulic oil level.

Hydraulic Oil Change

1. Position drain pan under the hydraulic reservoir. (reservoir capacity exceeds 15 gallons, be sure drain pans have adequate capacity)
2. Remove drain plug from bottom of reservoir and drain oil.
3. Return used oil to a recycling center.
4. Replace drain plug using pipe sealer on threads.
5. Fill reservoir with hydraulic oil to about 3 to 4 inches from the top of the tank. (approx 15 gal.)

Strainer Screen Service

1. Position drain pan under the hydraulic reservoir. (reservoir capacity exceeds 15 gallons, be sure drain pans have adequate capacity)
2. Remove drain plug from bottom of reservoir to drain oil.
3. Replace drain plug using pipe sealer on threads.
4. Remove hose clamps and 1¼" suction hose from nipple on hydraulic reservoir tank.
5. Unscrew king nipple from street-el.
6. Unscrew strainer from tank and clean in solvent.
7. Apply pipe sealer to threads and reinstall strainer and king nipple.
8. Attach 1¼" suction hose to king nipple and tighten clamps.
9. Refill hydraulic reservoir with hydraulic oil.
10. Check for leaks.

Heat Transfer Oil Maintenance

Heat Transfer Oil Level Check

1. Remove oil fill cap on top of expansion tank.
2. Cold oil level should be at the lower notch and the hot level at the upper notch in the dipstick. The cold level may also be checked by removing the cold oil level plug located to the lower left of the control panel on the rear of the machine.
3. Allow unit to cool, then add heat transfer oil as necessary, use Heat Transfer Oil with a minimum flash point of 550° F. C.O.C.
4. Replace oil fill cap.

Heat Transfer Oil Change

1. Allow unit to cool to ambient temperature.
2. Approx. oil capacities are 20 gal (OJK75), and 25 gal (OJK125), have suitable containers ready to contain oil.
3. Remove the drain plug from lower rear of unit and drain oil into drain pan(s). Note; If optional overnight heater is installed, remove to allow the oil to drain.
4. Replace drain plug and return oil to a recycling center.
5. Remove oil fill cap and add oil to the cold fill mark on the dipstick, or until oil flows from the cold oil level plug on the rear of the machine. Use Heat Transfer Oil with a minimum flash point of 550° F. C.O.C.
6. Heat unit to normal operating temperature and verify oil is half full in the expansion tank.

Packing Adjustment, Hot Oil Pump

Note: The packing gland requires a small amount of leakage (one drop every couple minutes) for lubrication, if leakage becomes excessive, adjust only enough to stop the excessive leakage.

1. Stop Engine.
2. Tighten 2 nuts on adjusting plate equally to control leakage. (Do not over tighten)
3. Start machine and check amount of leakage.
4. Readjust as necessary.

Important

WARNING

The proper heat transfer oil level is critical to the safe operation of this equipment. The most accurate way to check the oil level is when the unit is at operating temperature, however, extreme caution must be used since the dipstick and the oil are very hot and will cause severe burns. Wear leather gloves, eye and face protection, and other appropriate safety gear when checking the oil level.

It is important that the oil level (when hot) be approximately half full in the expansion tank. Allow the unit to cool before adding oil. Do not allow any water or moisture to be introduced into the system.

Note: The heat transfer oil will expand approximately 10 to 15% when heated from 60°F to 400°F. Make allowance for this when adding oil to a cold system.

Note: The unit is shipped with LUBE-TECH Ace Heat Transfer Oil 460. Use this or an equivalent heat transfer oil.

Burner Maintenance

Fuel Filter Replacement (burner)

1. Close fuel shut off valve located at the fuel tank.
2. Remove the nut securing the canister to the fuel filter body.
3. Remove the canister and the filter element.
4. Replace the element with a new one.
5. Reinstall the canister and turn on the fuel valve.
6. Attach a clear hose to the fuel pump bleeder screw on the burner and direct the hose into a suitable container.
7. Start engine, set thermostats, then turn on the burner power switch. This will allow the fuel pump in the burner to run so the fuel system can be bled of air.
8. Loosen the bleeder screw and observe the flow of fuel through the clear hose, when all air is purged from the system close the bleeder screw.
9. Check entire fuel system for leaks.
10. Set the thermostats to the desired level and the burner will ignite.

Brush Inspection (Every 300 hours)

1. Using a screwdriver, remove 2 brush holders located on the exterior of the motor housing and remove the brushes.
2. Replace brushes if less than 1/4 inch in length.

Combustion Chamber Inspection

1. Allow unit to cool to ambient temperature.
2. Remove 6 nuts and washers securing combustion chamber cover and remove cover.
3. Inspect heat transfer tubes for any signs of leaks, cracks, or deformation.
4. Using a pick or similar tool, probe the heat transfer tubes for any sign of flaking, scaling, distortion, thin metal or other deterioration.
5. Inspect insulation support clips for damage.
6. Inspect end diffuser plate for cracking or warping.
7. Inspect liner for cracks, excessive deformation, or other signs of deterioration.
8. Inspect entire combustion chamber area for any other signs of leakage, damage or fatigue.
9. Reinstall cover if no damage is found.
10. If any damage is found it must be repaired before returning the unit to service. Contact Stepp Mfg (651) 674-4491 for replacement parts.

Combustion Chamber Liner and Heat transfer tube replacement.

1. Allow unit to cool to ambient temperature.
2. Remove 6 nuts and washers securing combustion chamber cover and remove cover.
3. Remove the bolt that locks the hot-oil valve in the open position and close the valve.
4. Remove the heat transfer oil hose connections at the inlet and outlet of the heat exchanger. Cap the inlet and outlet ports to prevent oil spillage in the combustion chamber when the tubes are removed.
5. Remove the six bolts securing the heat transfer tubes to the combustion chamber housing.
6. Remove Fuel lines and electrical connections from burner.
7. Remove four bolts from burner flange and remove burner.
8. Lift heat transfer tubes and liner from combustion chamber housing.
9. Replace any insulation that is damaged or soaked with fuel or oil. Be sure to replace only with the same type insulation, contact Stepp Mfg for the proper insulation.

Liner and Heat transfer tube replacement (continued)

10. Install liner into heat transfer tubes.
11. Install liner & tube assembly into the combustion chamber housing.
12. Install the six bolts securing the heat transfer tubes to the combustion chamber housing.
13. Slide the liner to the end of the housing where the burner is mounted, then install the retaining clip over a tube and weld to the liner. Note: Do not weld on the heat transfer tubes.
14. Install the burner on the flange and install the four bolts.
15. Reconnect the fuel lines and electrical connections to the burner.
16. Reconnect the heat transfer oil hose connections at the inlet and outlet of the heat exchanger.
17. Open the hot oil valve and lock (bolt) in the open position. *Note: Operation of the burner with the valve closed will result in severe damage to the heat exchanger assembly.*
18. Reinstall the combustion chamber cover with six nuts and washers.
19. Check the heat transfer oil level and add as necessary.
20. Start the engine and allow to run for ten (10) minutes prior to igniting the burner. This will purge any air out of the heat transfer tubes before subjecting them to the heat from the burner.

Hot Asphalt Hose Replacement

CAUTION Do not remove hose without first removing the heating element or damage to heating element will result.

Hose Removal:

1. Remove heating element from hose. (refer to heating element removal procedures)
2. Disconnect all electrical connections from hose.
3. Separate the hose from the wand at the quick coupling.
4. Remove the quick coupling from the hose and save for reuse on the new hose.
5. Unscrew the hose from the *cross* fitting at the end of the boom assembly.

Hose Installation:

1. Screw the hose fitting into the *cross* fitting at the end of the boom assembly and tighten securely.
2. Screw the quick coupling to the other end of the hose and tighten securely.
3. Reconnect all electrical connections to hose.
4. Re-install heating element into hose, but do not reconnect electrical connector at this time. (note: the heating element will protrude about 10" from the end of the hose)
5. Gently heat the end of the wand with a propane torch. This will soften the material in the wand for easy insertion of the protruding hose heating element. (see next step)
6. Connect the hose to the wand at the quick coupling. Use gentle pressure to insert the protruding hose heating element into the wand.

CAUTION Do not apply power to the hose heating element in an empty hose or damage to the hose will result.

7. Bring material in tank up to operating temperature. (refer to operating instructions)
8. Verify hose heating element is disconnected.
9. Activate wand and boom heat for 20 minutes.
10. Pump material through wand until flowing freely. (refer to operating instructions)
11. Stop pump. Connect hose heating element connector. The hose is now full of material and the unit can be returned to service.

Hose Heating Element Replacement (Functioning Element)

Hose Heating Element Removal:

These instructions assume the heating element is functioning properly. If the heating element does not function, refer to the instructions on the following pages.

Note: If the hose is damaged, skip steps 1 through 3, activate wand heat for 15 minutes, then begin at step 4.

1. Start the engine and the burner and allow the product to reach operating temperature. Activate wand heat switch. Begin circulation of material through the wand into the re-circulating flange when temperatures permit. When product is circulating freely proceed to step 2.
2. Turn OFF the electric wand heat. Then with wand valve open, and the wand pressure control valve in the "wand" position, reverse the pump for 2 minutes to clear the hose, wand, and boom of material.
3. Shut OFF the burner and the engine.
4. Disconnect the hose heating element connector at the end of the boom.

Note: *The following steps must be accomplished with all components warm.*

5. Remove the compression fitting that holds the hose heating element at the top of the "cross" fitting on the end of the boom.

WARNING *The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.*

CAUTION *Do not pull on the wires to remove the heating element or damage to the element may result.*

6. Gently pull the heating element from the "cross" fitting and the hose.

Hose Heating Element Installation:

1. Remove wand from hose at quick coupling.
2. Lay the hose out as straight as possible.
3. Install new compression fitting into *cross* fitting.

If hose does *not* contain material proceed with step 4.

If hose *contains* material, replace step 4 with steps A & B listed below.

4. Insert heating element into compression fitting and hose. (About 10" of the heating element will protrude out the other end of the hose) Tighten compression fitting.
5. Insert protruding element into wand and reattach wand to hose at quick coupling. (gently heat wand with propane torch to ease installation if needed)
6. Reconnect all electrical connections.

CAUTION *Do not apply power the hose heating element in an empty hose or damage to the hose will result.*

7. Bring material in tank up to operating temperature. (refer to operating instructions) and activate wand heat.
8. Pump material through wand until flowing freely. (refer to operating instructions) The hose is now full of material and the unit can be returned to service.

Steps A & B

A. Connect one lead of the heating element to the large terminal of the 24V alternator, and the other lead to a good chassis ground. Use 10 gage (minimum) jumper wires.

WARNING The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.

B. Start the engine, as the heating element heats, insert it into the hose. Start and stop the engine, or disconnect the jumper wires, as needed to regulate the heat of the element. Use only enough heat to soften the material and allow the element to be pushed into the hose. (About 10" of the heating element will protrude out the other end of the hose) Tighten compression fitting.

Proceed to step 5 above.

Hose Heating Element Replacement

(Non-Functioning Element)

Hose Heating Element Removal and Installation:

These instructions assume the heating element is damaged and *not* functioning. If the heating element functions properly, refer to the instructions on the preceding page. The element may be damaged during removal rendering it useless.

A functioning hose heating element is slid into the hose along side the non-functioning element. As the material in the hose is heated with the new element, the old element can be pulled from the hose.

1. Remove wand from hose at quick coupling. About 10" of the hose heating element protrudes out the hose and into the wand. Gently heat wand with propane torch to ease separation if needed.
2. Disconnect the hose heating element connector at the end of the boom.
3. Remove the compression fitting nut that holds the hose heating element at the top of the "cross" fitting on the end of the boom. Then remove the complete compression fitting.
4. Pull the element out and to the side far enough to allow a new element to be slid in along side the old element.
5. Slide a new compression fitting assembly onto the new heating element, but do not tighten.
6. Connect one lead of the new element to the large terminal of the 24V alternator, and the other lead to a good chassis ground. Use 10 gage (minimum) jumper wires.

WARNING *The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.*

7. Start the engine, as the heating element heats, insert it into the hose along side the old element. Start and stop the engine, or disconnect the jumper wires, as needed to regulate the heat of the element. Use only enough heat to soften the material and allow the element to be pushed into the hose.
8. Pull the old heating element from the "cross" fitting and the hose.
9. Secure new heating element in compression fitting, then reconnect electrical connector.
10. Insert protruding hose element into wand and reattach wand to hose at quick coupling. (gently heat wand with propane torch to ease installation if needed)

Wand & Boom Heating Element Replacement

Wand or Boom Heating Element Removal and Installation:

These instructions assume the heating element is damaged and *not* functioning. The element may be damaged during removal rendering it useless.

A functioning heating element is slid into the wand or boom along side the non-functioning element. As the material is heated with the new element, the old element can be pulled from the wand or boom.

1. Remove wand from hose at quick coupling. About 10" of the hose heating element protrudes out the hose and into the wand. Gently heat wand with propane torch to ease separation if needed.
2. Remove the compression fitting nut that holds the heating element in the wand or boom. Then remove the complete compression fitting.
3. Pull the element out and to the side far enough to allow a new element to be slid in along side the old element.
4. Slide a new compression fitting assembly onto the new heating element, but do not tighten.
5. Connect one lead of the new element to the large terminal of the 24V alternator, and the other lead to a good chassis ground. Use 10 gage (minimum) jumper wires.

WARNING *The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.*

6. Start the engine, as the heating element heats, insert it along side the old element. Start and stop the engine, or disconnect the jumper wires, as needed to regulate the heat of the element. Use only enough heat to soften the material and allow the element to be pushed into the wand or boom.
7. Pull the old heating element from the wand or boom.
8. Secure new heating element in compression fitting, then reconnect electrical connector.

An alternate method is to remove all insulation from the wand or boom. Then heat as needed with a torch to soften the material allowing removal and installation of the heating element.

TROUBLE SHOOTING

HYDRAULIC SYSTEM



	<i>POSSIBLE CAUSE</i>	<i>Items to Check /Service</i>
LACK OF PERFORMANCE	Plugged Strainer Screen	Service strainer screen
	Hydraulic Filter Plugged	Replace hydraulic oil filter
	Collapsed Suction Hose	Replace suction hose and service strainer screen
	Air Leak in Suction Hose	Replace hose.
	Low Fluid Level	Fill Reservoir to proper level.
	Over Heated Hydraulic Fluid	Clean oil cooler fins with pressurized water.
	Worn Pump or Hydraulic Motor	Adjust, rebuild, or replace as necessary.
	Crushed Hydraulic Lines	Replace line.
	“Brand” valve relief out of adjustment	Adjust relief on “Brand” valves to 1000 lbs.
HYDRAULIC MOTORS DO NOT TURN OR TURN SLOWLY	Product in Tank not Melted	Allow for more time for product to melt
	Foreign Material Jamming Agitator	Remove foreign material from agitator.
	Foreign Material Jamming Product Pump	Remove foreign material from product pump.
	Also see “Lack of Performance”	
UNUSUAL NOISES	Low Hydraulic Fluid	Fill reservoir to proper level.
	Air Leak in Suction Hose	Replace Hose
	Damaged Pump or Hydraulic Motors	Repair or replace as necessary
EXCESSIVE OIL LEAKS FROM PUMP OR HYDRAULIC MOTOR SHAFT	Bad Shaft or Shaft Seal	Replace as necessary.

PRODUCT DELIVERY



	<i>POSSIBLE CAUSE</i>	<i>Items to Check /Service</i>
PRODUCT PUMP DOES NOT TURN	Product in Tank not Melted	Allow more time for product to melt.
	Foreign Material Jamming Product Pump	Remove foreign material from product pump
	Pump Motor not Functioning	Refer to “Hydraulic System” Trouble Shooting
LACK OF FLOW FROM WAND	Product Temperature too Cold.	Heat product to manufacturers recommended temperature.
	Product “Froze” in Wand & Hose	Allow additional time for heating element to melt product in hose.
	Non-functioning Heat Element in Hose	Refer to “Electric Wand & Hose” Trouble Shooting
	WPC Valve not Positioned Correctly	Refer to operating instructions for WPC Valve position.
	WPC Valve and External Plumbing “Froze”	Heat to re-melt product
	Worn Product Pump	Adjust or repair product pump as necessary.


TROUBLE SHOOTING

PRODUCT PUMP



Electric Wand & Hose Troubleshooting





Diesel Burner Component Test

Primary Controller Burner mtd/hard wired. The Primary Controller can be bench tested for proper operation using an automotive type 12 volt battery as a power source. Refer to the wiring schematic for wire identification.

1. Remove Controller from burner. Mark all wires for proper reassembly.
2. Using 2 test lights or volt meters, connect one to the blue wire, and one to the white/orange wire of the Controller. Connect the black leads of your test instruments to neg. (-) terminal of battery.
3. Connect the black wire from the Controller to neg. (-) terminal of battery.
4. Connect the red, white/red, and the white wires together, then connect these 3 wires to battery (+)terminal. Both test instruments should show voltage for approximately 15 seconds. After 15 seconds the controller should "lock out" and no voltage will be present.
5. Repeat step 4, only this time connect the 2 yellow wires from the Controller together 3 seconds *after* applying power to the 3 wires of the Controller.

(This simulates the controller receiving a "flame" signal from the Photo Electric Eye)

The white/orange wire should show voltage as long as the controller is hooked to the battery. The blue wire should only show voltage for about 15 seconds.

Replace the controller if it fails any of these tests.




Photo Electric Eye

The Photo Electric Eye can be bench tested for proper operation using an ohm meter. Assure the lens of the Photo Electric Eye is clean prior to testing.

1. Block off all light to the Photo Electric Eye. Test across the leads with your ohm meter, you should get an infinite resistance reading. (a lot of resistance)
2. Point the Photo Electric Eye at a light source, the brighter the light, the less resistance your ohm meter will show.

Replace the Photo Electric Eye if it does not respond in this way.

Fuel Valve


The Fuel Valve can be bench tested for proper operation using an automotive type 12 volt battery as a power source.

1. Disconnect the 2 leads and remove the fuel lines from the Fuel Valve.
2. The valve should be closed when no power is available.
3. Apply 12 volts to the 2 leads and the valve should open.

Replace the Fuel Valve if it does not respond in this way.

Ignition Transformer **WARNING - Shock Hazard, High Voltage up to 20,000 volts.**


1. Assure that 12 volts is being supplied to the transformer during the ignition cycle. (Refer to the Primary Controller tests.)
2. Check electrode condition and adjustment. Replace or adjust as necessary. Replace Ignition Transformer if unit won't produce sparks.



LP BURNER

LP Burner Spark Ignition

TROUBLE SHOOTING



Fuel Valve Solenoid

The fuel solenoid valve needs to be removed to perform this test. 12 volts applied to the fuel solenoid valve activates an electromagnet that pulls the valve open. With no power applied a spring pushes the valve closed, blow through the valve to verify proper operation. Replace valve if not functioning properly.

Fenwal Ignition Control


The Fenwal Ignition Control creates sparks at the electrodes for igniting the pilot light, and supplies power to the fuel valve at the appropriate times. The controller receives voltage from either the thermostat or main power switch (depending on the system) to begin operation. A flame sensing circuit is incorporated for control of the fuel valve if the flame goes out.

When the power switch is turned on, or when the thermostat calls for heat, a 12 volt signal is sent to the controller. The controller will then create sparks at the electrodes. At the same time the controller also sends a 12 volt signal to the fuel valve causing it to open. This allows fuel into the pilot light and it is ignited by the sparks at the electrodes. The flame sensing circuit will signal the controller that ignition was successful. The controller will then shut off the sparks. The fuel valve will remain open to keep the flame burning.

If the controller does not sense a flame within approximately 6 to 7 seconds, it will shut off the fuel supply and the sparks. The controller will then "lock out".

If the flame should go out for any reason, the controller will try for re-ignition, if re-ignition is not successful in 6 to 7 seconds, the controller will "lock out".

If a lock out situation occurs, the main power switch must be shut off, then on again, to reset the system. (continued on next page)



Fenwal Ignition Control


The Ignition Controller can be tested for proper operation using an automotive type 12 volt battery as a power source. A propane torch, and a 12 volt test light will also be needed. Do not use a digital volt/ohm meter as it may give false readings for these tests.

1. Disconnect wires as necessary to perform these tests. Mark all wires for proper reassembly.
2. Connect one lead of your test light to the brown wire from the fuel valve.
Connect the other lead to neg. (-) terminal of battery.
3. Be sure the yellow wire from the controller is connected to ground. (neg. terminal of battery).
4. While observing your test light, apply power to the red wire on the controller by turning on the main power switch and thermostat (if equipped). The test light should light up and sparks will be present at the electrodes for approximately 6 seconds, then the Controller should "lock out". The sparks will stop and the test light will go out.
5. Repeat step 4, only this time direct flame from a propane torch across the sensing and ground electrodes 2 seconds *after* applying power to the Controller.

The sparks should stop and the brown wire (fuel valve) should show voltage as long as the flame is directed across the electrodes.

Remove the flame and the sparks should reappear for 6 seconds, this is the trial for re-ignition. If the flame is not reestablished, the system "locks out",


Be certain all wiring is correct and undamaged, then replace the controller if it fails any of these tests.



REPLACEMENT PARTS

REPLACEMENT PARTS

DIESEL BURNER



F HEAD FIRING RATE CHART

HEAD	F-3	F-6	F-12	F-22	F-31
MIN. FIRING RATE	.75	1.25	1.65	1.75	2.50
MAX. FIRING RATE	1.25	1.65	2.00	2.50	3.00

NOZZLE FLOW CHART

100 PSI	.75	.85	.90	1.00	1.10	1.20	1.25	1.35	1.50	1.65	1.75	2.00	2.25	2.50	2.75	3.00
140 PSI	.89	1.00	1.07	1.18	1.30	1.41	1.48	1.60	1.78	1.95	2.07	2.37	2.66	2.96	3.25	3.55


ITEM	QTY	DESCRIPTION	PART#
1	1	Burner, fuel oil, Beckett Assembly	A10008105-011
2	1	Air Tube	509070
3	1	Photo electric eye w/connectors (under ignition transformer)	A10007678
4	1	Valve, fuel control	509091
5	1	Ignition Transformer	509087
6	1	Primary Controller	A10008216
7	1	Motor, fan and pump	509092
8	1	Coupling, pump to motor	509086
9	1	Pump, burner fuel	509094
10	1	Fuel retention head, F31	P10005130
11	1	Nozzle, .3.0 GPM	P10005133
12	1	Electrode kit, igniter	509089
13	1	Mounting Flange	509071
**	1	Brush kit, motor	509072
**	1	Fuel Filter Element	509078

** Not Shown

Note: Nozzle GPH rated at 100 psi.

LP BURNER


REPLACEMENT PARTS




ITEM	QTY	DESCRIPTION	PART#
1	1	Orifice, main burner	call
2	1	Burner assembly	call
3	1	Pilot light, spark ignition	901101
4	1	Ignition electrode & flame sensor assy.	P10005738
5	1	Low voltage cable assembly	P10005737
6	1	Ignition control box	P10005719
7	1	High voltage cable assembly	P10005736
8	1	Orifice, pilot light, .035	P10005718
9	2	LP Solenoid valve assembly, 12V	P10005720
**	2	Solenoid winding only, for LP Solenoid valve	509051
10	1	Pressure gauge	P10005630
11	1	Lp filter (element only)	509028
12	2	LP relief valve (location may vary)	P10005656
13	1	LP regulator	P10002936
14	1	Pre-orifice, pilot light, .013	509005
15	1	Strainer, pilot light	P10005653
16	1	Valve, pilot light	P10005652
17	1	Valve, burner - V104	P10005655
18	1	.25 x 5' LP hose	P10005685
	1	.25 x 10' LP hose (optional)	523004
19	1	Pol fitting, liquid LP - female (recommended)	P10005657
20	1	Pol fitting, vapor LP - male	509021

(** Not Shown)

REPLACEMENT PARTS




CONTROLS



ITEM	QTY	DESCRIPTION	PART#
1	-	Thermostat, Watlow 0-550°, EZ 12V	EZ-ZONE- P10003540
2	-	Sensor, RTD Watlow 0-550°	A10001017
3	-	Switch- SPST Toggle ON/OFF	P10000180
**	-	Switch- ON/OFF/ON	P10002877
4	-	Light- Call For Heat 12V	P10000181
**	-	Hour Meter	P10002722
5	-	20 Amp Breaker	P10000179
** Not Shown			

OVERHEAD BOOM

REPLACEMENT PARTS



ITEM	QTY	DESCRIPTION	PART #
1	1	Boom	901280
2	1	Latch, boom transport and safety	901283
3	1	Support bearing	502006
4	1	Boom support (OJK 75 & 120)	901281
5	1	Boom swivel	520007
6	1	Union, 3/4"	513202
7	2	Nipple, 3/4" close	513211
8	1	Valve, 3-port WPC, 3/4"	517022
9	1	Bushing, reducing 1" x 3/4"	513706
10	1	Thermometer, 550 F. with 6" stem	516001
11	1	Cross Fitting	513254
12	1	Bushing, reducing 1" x 3/8"	513709
13	1	Compression Fitting 3/8"	520232
14	1	Heating Element, boom, includes *pre-wired connector	526112
*	9 ft	Inner Insulating for boom (specify length, priced per foot)	511007
*	8 sq ft	Outer Alumagard wrap for boom (specify length, priced per sq. foot)	511008
*	1	Wire Harness, boom	526115


* - Not Shown

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

8'/12' Heated Hose

For Units equipped with 8'/12' Heated Hose w/Heated Overhead Boom




ITEM	QTY	DESCRIPTION	PART #
1	1	8' Hose Assembly with heating element	523089
	1	12' Hose Assembly with heating element	523093
1a	1	Compression Fitting 3/8"	520232
1b	1	8' Heating element, for hose, includes **connector	526112
	1	12' Heating element, for hose, includes **connector	526120
1c	1	8' Hose Assembly, less heating element	523088
	1	12' Hose Assembly, less heating element	523092
1d	AR	Safety Jacket, specify length	523080
1e	2	Clamp assembly (torque bolts to 21 ft lbs)	523087
**	1	Wire Harness & Connectors (in hose jacket)	Call
2	1	Bushing, reducing	513709
3	1	Bushing, reducing	513706
4	1	Quick Coupling, female	510003
4a	1	Seal, quick coupling	509999

** - Not Shown

15'/20' HEATED HOSE

REPLACEMENT PARTS




ITEM	QTY	DESCRIPTION	PART #
1	1	Compression Fitting assembly	523260
2	1	Bushing, reducing	513701
3	1	Plug	513208
4	1	Cross Fitting	513203
5	2	Nipple, close	513211
6	1	Valve, 3-port WPC	517022
7	1	Union	513202
8	2	Hose End	523084
9	2	Clamp assembly	523087
10	-	Hose only, specify 15 or 20 ft.	523083
11	1	Seal, quick coupling	509999
12	1	Quick Coupling, female	510003
13	1	Heating element, 15 ft.	526072
		Heating element, 20 ft.	526073
14	-	Safety Jacket, specify 15 or 20 ft.	523080
**	1	Hose Assembly Complete, 15 ft. (includes items 1-5, 7-10, 13-14)	523085
**	1	Hose Assembly Complete, 20 ft. (includes items 1-5, 7-10, 13-14)	523086
**	1	Hose Assembly, 15 ft. (less heating element, includes items 8-10, 14)	523081
**	1	Hose Assembly, 20 ft. (less heating element, includes items 8-10, 14)	523082

** - Not Shown. Specify with or with out pump saver option.

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

TRIGGER WAND




ITEM	QTY	DESCRIPTION	PART #
1	1	Wand assembly , LONG Trigger Style	204056
	1	Wand assembly, SHORT Trigger Style	204058
1a	1	Handle, Adjustable Slide	520022
1b	1	Switch, Trigger	526116
**		Wire Harness, Ultra-Lite Wand	Call
2	1	Heating Element, LONG Style	526113
	1	Heating Element, SHORT Style	526118
3	1	Compression Fitting, LONG Style 1/2"	523260
	1	Compression Fitting, SHORT Style 3/8"	520232
4	1	Quick coupling, Male Half	510002
**	1	Ball Valve w/Handle 1/2" , SHORT Style only	517047

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

HEATED WAND

REPLACEMENT PARTS




ITEM	QTY	DESCRIPTION	PART #
1	1	Heating Element	526074
2	1	Compression Fitting	523260
3	1	Quick Coupling, male	510002
4	10 ft	Insulating Wrap, wand	520114
5	1	Mounting Bracket, switch (pump saver option only)	Call
6	1	Switch, pump saver (pump saver option only)	526057
7	1	Control Handle, for steel wand	Call
8	1	Control Handle with bushing, for aluminum wand	Call
9	1	Steel Spray Wand Assembly (includes items 4, 7-9)	Call
9	1	Aluminum Wand, light weight, optional (includes items 4, 7-9)	Call
10	1	Actuating Rod	Call
10	1	Lever, valve	Call
11	1	Valve	517006
12	1	Spray Nozzle, ¼U9508	520060

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

NON HEATED WAND




ITEM	QTY	DESCRIPTION	PART #
1	1	Wand assembly complete, steel (Includes items 1 - 4)	204004
	1	Wand assembly complete, light weight aluminum (Includes items 1 - 4)	204026
2	1	Valve	517006
3	1	Coupling	513809
4	1	Spray Nozzle, 9508	520060

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

PRODUCT PUMP DRIVE LINE


REPLACEMENT PARTS



ITEM	QTY	DESCRIPTION	PART #
1	1	Motor, Hydraulic	Call
2	1	Woodruff Key, 1/4" x 1"R	522048
3	1	Chain Coupling Half, 1" bore	507058
4	1	Coupling Chain, 4016	507056
5	1	Chain Coupling Half, 1 1/8" bore	507059
6	1	Drive Key, 1/4" x 1 1/2" L	522043
7	1	Product Pump (refer to Product Pump parts break down)	Call

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.


Haight 10 - 40 D/DR



<u>ITEM</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1-14	Product Pump, Complete	515049
13	Packing	515054

ALERNATOR/HYDRAULIC PUMP DRIVE

REPLACEMENT PARTS




ITEM	QTY	DESCRIPTION	PART #
1	1	Stub Shaft, diesel engine only	901230
2	1	Adjusting Bracket, alternator, for diesel engine only	Call
3	1	Alternator, 24 volt	526058
4	2	V-Belt, alternator, diesel engine	514013
	2	V-Belt, alternator, gas engine	514011
5	1	Pulley	514020
6	1	Bushing, Pulley (includes bolts)	514022
7	1	Coupling Half, 1" bore	507063
8	1	Spider	507067
9	1	Coupling Half, 5/8" bore, used with diesel engine	507064
	1	Coupling Half, 9/16" bore, used with gas engine	507066
10	1	Pump, Hydraulic, used with diesel engine	510073
	1	Pump, Hydraulic, used with gas engine	510064

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

AGITATOR



ITEM	QTY	DESCRIPTION	PART #
1	1	Hydraulic Motor	510004
2	1	Drive Adaptor	Give serial number
3	1	Agitator	Give serial number
4	1	Thrust Bearing, agitator	502008

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts. Part description and unit serial number are required to place orders for parts without numbers.


MISC.

REPLACEMENT PARTS

<u>ITEM</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART#</u>
00	1	Main burner power switch	526039
00	1	Red 12v heat light	526038
00	1	20 amp circuit breaker	526094
00	1	Charging Resistor	526059
00	1	Fuel Pump, electric	Call
00	1	Oil drain valve, engine	508050
00	1	Fuel Gauge	509080
00	1	Cap Assembly, fuel tank	513414
00	1	Cap, hydraulic tank	513522
00	1	Warning Label and Decal Kit	Call
00	-	LUBE-TECH Heat Transfer Oil 460, 55 gallon drum.	603017
00	-	LUBE-TECH Heat Transfer Oil 460, 5 gallon pail.	603019
		(Used in oil jacketed equipment <i>without</i> oil circulation pumps)	
		(Refer to maintenance manual for oil capacities)	

REPLACEMENT PARTS

BRAKES AND AXLES



ITEM	QTY	DESCRIPTION	PART#
1	1	Magnet, electric brake (1 required for each wheel)	Give Serial #
2	1	Brake Shoe Set (1 set required for each wheel)	Give Serial #
3	1	Brake Drum and Hub assembly (1 required for each wheel)	Give Serial #
4	1	Leaf Spring assembly (1 required for each wheel)	Give Serial #
Complete replacement axle assemblies are available and include brakes, hubs, and springs.			
5	1	Axle assembly, complete, call for ordering information	Give Serial #
*	4	Wheel, call for ordering information	Give Serial #

* - Not Shown

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.


ORDERING INFORMATION:

Orders for suspension parts must include the equipment serial number.

Orders for brake parts must include the equipment serial number and brake drum dimensions. (diameter and width) Also specify electric or hydraulic brake system.

MISC.

REPLACEMENT PARTS



ITEM	QTY	DESCRIPTION	PART#
1	1	Over night heater, electric (optional)	520097
2	1	2.5" doc, draw-off valve	107006
3	1	Switch, heated hose and wand	526080
4	1	Oil Pressure Gauge	Call
5	1	Water Temperature Gauge	Call
6	1	Hour Meter	508038
7	2	Switch, pump saver & safety loading	526057

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

NHTSA Reporting Safety Defects

If you believe that your vehicle has a defect in which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying STEPP MANUFACTURING CO., INC..

If NHTSA receives similar complaints, it may open an investigation and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or STEPP MANUFACTURING CO., INC..

To Contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or Write to: NHTSA, US Department of Transportation, 1200 New Jersey Ave., S.E., Washington DC 20590. You can also obtain information about your motor vehicle safety from <http://www.safercar.gov>.

WARRANTY GUIDE

Stepp Mfg. Co.

Consumer Warranty Guide

	Page
Table of Contents	
Introduction	2
Warranty Procedures Through A Dealer	2
Warranty Procedures Direct Through The Factory	2
Engine Warranty Claims	2
Equipment Owner Responsibilities	2
General Warranty Statement	3
Pro Rata Heated Asphalt Hose & Element Warranty	4

Stepp Manufacturing Co Inc

12325 River Road • North Branch MN 55056-6225

Phone (651)674-4491 • Fax (651) 674-4221

jason@Steppmfg.com www.SteppMfg.com

Introduction

Congratulations on your purchase of Stepp Asphalt Maintenance Equipment. Your equipment has been designed and constructed to give you the most in performance, ease of use, and reliability. It is our desire that you will find operating the equipment both productive and profitable.

This Warranty Guide has been prepared to help you in the unlikely event that your equipment requires warranty service. You can rest assured that Stepp Mfg will assist in any way we can to get your equipment repaired and back on the job as quickly as possible.

Warranty Procedures Through A Dealer

If your equipment requires repair during the warranty period, contact your dealer and arrange to bring the unit to him for repair. The dealer will require purchase date information, where the machine was purchased, and the serial number of the equipment. This information is needed so the dealer can submit a warranty claim. The dealer will repair your equipment at no charge to you under the provisions of the warranty policy.

Warranty Procedures Direct Through The Factory (When there is no servicing dealer in your area)

Contact Stepp Mfg at (800)359-8167 if there is no servicing dealer located in your area.

In this situation it may be advantageous for you to repair the machine and be reimbursed direct from the factory for warranty repairs. If you do not have the facilities or the technicians to perform the repair, the unit can be brought to a local repair facility for the warranty work. In either case Stepp Mfg *MUST* be contacted and a *Warranty Authorization Number* issued prior to any work being performed.

If parts are required for the warranty repair, contact Stepp Mfg for replacements. When warranty replacement parts are shipped to you, a prepaid UPS shipping label will be included. Be sure to “tag” the defective parts with the *Warranty Authorization Number* then package them in the same box the new parts were shipped in. Affix the UPS shipping label to the outside of the box and return to Stepp Mfg as soon as practical.

You will be billed for all parts shipped, however, when the defective parts are returned and evaluated, you will receive credit for the cost of the parts plus any shipping charges. Thus it is important that all defective parts are returned to Stepp Mfg in a timely matter.

Engine Warranty Claims

When a warranty issue develops with the engine, bring the unit to the engine manufacturer's nearest authorized service center for repair. Be prepared to supply them with proof of purchase information with purchase dates.

Stepp Mfg can not process engine warranty claims, however we will be happy to offer assistance in locating the nearest service center.

Equipment Owner Responsibilities

As the equipment owner you are responsible for:

- Using the equipment in accordance with the correct operating procedures as shown in the operators manual.
- Assuring all maintenance items are completed in accordance with the operators/maintenance manuals.
- Transporting the equipment to the place where warranty repairs can be completed.
- Supplying purchase date and serial number information to establish warranty coverage.

Stepp Manufacturing Co Inc

12325 River Road • North Branch MN 55056-6225

Phone (651)674-4491 • Fax (651) 674-4221

jason@Steppmfg.com www.SteppMfg.com

General Warranty Statement

Stepp Mfg 1 Year Limited Warranty

Stepp Manufacturing Company Inc. hereby warrants to the original purchaser that products manufactured by Stepp Mfg will be free from defects in material and workmanship for a period of 1 year from the date of purchase.

Stepp Mfg, at its discretion, will provide for the repair or replacement of any part found upon examination by Stepp Mfg to be defective, except as noted below. Such repair or replacement will be free of charge to the original purchaser for a period of 1 year from the date of purchase, except as noted below.

No warranty is extended to cover:

- Product pump wear or damage caused by foreign object.
- Routine maintenance, cleaning, and adjustments.
- Parts or components that have been altered, misused, improperly adjusted or maintained.
- Transportation to and from the place of warranty repair.
- Removal of material from equipment.

The following items are covered solely by their manufactures warranty:

- Engines
- Hydraulic components
- Burners
- Pumps
- Tires
- Other component parts

The following items are covered by a pro rata warranty:

- Hoses that carry heated materials.
- Heating Elements for hoses and wands.

Disclaimer of further warranty:

Stepp Mfg makes no warranty, expressed or implied, other than this warranty. The implied warranties of merchantability and fitness for particular purpose are hereby disclaimed. Repair or replacement of products or parts proving to be defective in material or workmanship shall be the exclusive remedy for breach of this warranty.

Stepp Mfg shall not be liable for incidental or consequential damages. Including but not limited to, damages for inconvenience, rental or purchase of replacement equipment, for loss of profits, or other loss resulting from breach of this warranty.

Stepp Mfg reserves the right to incorporate any changes in design into its products without obligation to make such changes on products previously manufactured.

Stepp Manufacturing Co Inc

12325 River Road • North Branch MN 55056-6225

Phone (651)674-4491 • Fax (651) 674-4221

jason@Steppmfg.com www.SteppMfg.com



Heated Asphalt Hose and Heating Element 12 Month Pro Rata Limited Warranty

Effective for Oil Jacketed Kettles and Equipment Delivered After 8/1/00

Stepp Manufacturing Company Inc. hereby warrants to the original purchaser on a pro rata basis that the heated asphalt hose and hose heating element installed on new Stepp manufactured equipment will be free from defects in material and workmanship for a period of 12 months.

If a hose or heating element fails under normal use during the warranty period, Stepp Mfg will supply a replacement hose or heating element, and provide for ½ hour installation labor on a pro rata adjustment basis.

- If the failure occurs under normal use within the first 3 months, Stepp Mfg will supply a replacement and provide for ½ hour installation labor at no charge to the customer.

- If the failure occurs under normal use within the 4th through 12th months, Stepp Mfg will supply a replacement and provide for ½ hour installation labor on a pro rata basis.

The pro rata adjustment is based on the total number of months elapsed since the purchase date of the new equipment divided by 12. This rate is then applied to the ½ hour labor rate and the current suggested retail price of the proper replacement hose or heating element supplied by Stepp Mfg. This is the amount the customer will have to pay.

In no case will the warranty coverage extend beyond 12 months from the original purchase date of the new equipment. Physical damage is not covered by warranty. Physical damage may include but is not limited to:

- Broken heating elements (typically caused by repeated bending to less than a 1 foot radius).
- Hoses burnt from the inside (typically caused by operating the heating elements in an empty hose, refer to the operators manual for proper operating procedures).
- External cuts or abrasion on hose, etc.

The chart below shows the pro rated amount (percentage of retail price and labor) that warranty and the customer will pay towards a replacement hose or heating element under this warranty policy.

<u>Failure at</u>	Warranty pays	Customer Pays
0-1 month	100%	0
1-2 months	100%	0
2-3 months	100%	0
3-4 months	75%	25%
4-5 months	66%	34%
5-6 months	58%	42%
6-7 months	50%	50%
7-8 months	42%	58%
8-9 months	34%	66%
9-10 months	25%	75%
10-11 months	17%	83%
11-12 months	8%	92%
After 12 months	0	100%

Note: 30 days is considered a month. Example: Failure at 2-3 months means failure between 61 and 90 days.

Stepp Mfg. Co. Inc.

12325 River Rd. North Branch MN. 55056

Customer Name	Phone #	Equipment Model #	Equipment Serial #	
Street Address		Hour Meter	Purchase Date	
City/State	Zip Code	Purchased From (Dealer Name or Direct From Stepp Mfg)		
Warranty Performed By: Company Name			Date of Malfunction	
Address	City	State	Zip	Date of Repair
Contact Name	Signature			Phone #

Describe Symptom (be specific, e.g. "Burner ignites and runs for 35 seconds, then goes out." Wording such as "Burner does not work" is not adequate.)

Describe Problem Found (be specific, e.g. "Part failed due to loose connection resulting in misalignment and premature wear." Wording such as "faulty part" is not adequate.)

Action Taken to Correct Problem (be specific, e.g. "Removed damaged section of wire harness, soldered new leads in place and insulated splices with heat shrink tubing." Wording such as "repaired wiring" is not adequate.)

Labor Time to Correct Problem (if multiple repairs were made, list the labor time for each repair separately, or submit separate warranty claims) Repair	Office Use Only	Parts & Supplies Used in Repair QTY Description Part#	Office Use Only
Labor Time			

Parts Return

All parts replaced should be tagged with the warranty authorization number and a copy of the this claim. Retain all parts until credit, or a *Warranty Parts Return Request*, is received from the factory. When requested, returned the parts, along with this claim, to Stepp Mfg, 12325 River Road, North Branch, MN 55056. If defective parts are not returned within 10 days, or this warranty claim does not accompany the returned parts, the claim will be denied.

Office Use Only - Do not write in the area below.

Date Claim/Parts Received **Claim Reviewed By** **Date**

Is This A Warrantable Claim? ___ Yes ___ NO

Explanation:



Warranty Amount:

Parts

Labor

Total Credit

Credit Invoice #

Stepp Mfg

12325 River Road
North Branch MN
55056

Warranty Parts Return Request

Dealer/Service Center:

Reference:

- Warranty Authorization # _____ Dated _____
- Serial # _____
- Owner _____

Please return the parts listed below for warranty evaluation using the following procedure.

1. Attach this request to the parts.
2. Package parts for shipment.
3. Adhere the enclosed Pre-paid UPS Shipping label to the package.

Note: If no shipping label was sent with this request, call Stepp Mfg (800) 359-8167 with the package dimensions and weight, then a prepaid shipping label will be sent to you.

4. Ship package to Stepp Mfg within 10 days of the date of this request.

The following parts are requested to be returned for warranty evaluation.

(Note: Failure to return requested parts will result in denial of warranty coverage.)

<u>Qty.</u>	<u>Part Number</u>	<u>Description</u>
-------------	--------------------	--------------------

WATLOW PROGRAMMING

Watlow 12v Series PM Temperature Controller

Operators Programming Sequence for 12 volt devices. PN EZ-ZONE– P1003540

This programming sequence is taken from the manufacturers programming manual for this controller and reduced to eliminate the non-essential entries. Please follow the entries carefully and if any questions arise because of misunderstanding the instructions, see your supervisor or call the factory for clarification. **To view the entire EZ-Zone PM Controller Users Manual, go to www.watlow.com, search on *EZONE PM Users Manual*.**

If at any time during the entries you feel that you have entered an incorrect entry and want to restart the procedure from the beginning, simply press the Infinity key to return to Home Page from any page or parameter. After 60 seconds with no key presses, the controller reverts to the Home Page.



The EZ-Zone PM Controller has four menus that are used to determine the configuration and operation of the controller. They are the Home Page, Setup Page, Operations Parameters Page, and the Factory Page. If you are installing the EZ-Zone PM Controller, you will need to determine the proper settings for all pages. The controller is preset at the factory prior to delivery of the equipment and is ready for operations. Always confirm that the controller is programmed correctly and operating correctly under normal operating conditions.

Caution: Pay particular attention to the h.SP (High Temperature Set point) setting for max. product application temperature that is entered on the Setup Page at step 7-8.

Do not set the High Temperature Set Point any higher than the product manufacturer maximum application temperature recommendations. Do not hesitate to ask your supervisor or call the factory for the correct setting if any questions or concerns arise.

Watlow Series PM-12 volt controller

Sample Display Illustrations

- This display shows a typical temperature selection by the operator.
- Upper display shows actual product temperature in red color.
- Lower display shows operator desired maximum temp setting in green color.
- Set the desired maximum temp with the up and down keys.



Operator will not be able to exceed the maximum temperature set point as shown in the programming procedure in the following pages.

Do not hesitate to ask your supervisor for the correct setting if any questions or concerns arise.

Watlow Series PM-12volt Temperature Controller

Operators Programming Sequence for 12 volt devices

This programming sequence is taken from the manufacturers programming manual for this controller and condensed to eliminate the non-essential entries for ease of setup. Please follow the entries carefully and if any questions arise because of misunderstanding the instructions, please call the manufacturer for clarification.

If at any time during the entries you feel that you have entered an incorrect entry and want to restart the procedure from the beginning, simply press the up arrow and the down arrow at the same time to erase all entries and begin the procedure from the beginning.

Menu Structure and Programming

The Series PM Controller has four menus that are used to determine the configuration and operation of the controller. They are the Home Menu, Setup Menu, Operations Menu and the Factory Menu. If you are installing the Series PM Controller, you will need to determine the proper settings for all menus. If the controller is already installed in the equipment that you have purchased, you may only need to set a few of the parameters to adjust the controller to your specific usage of the equipment. The Setup Menu displays the parameters that configure the Series PM Controller to fit your application. When installed on new equipment, the controller is preset at the factory prior to delivery of the equipment and is ready for operations. Always confirm that the controller is programmed correctly and operating correctly under normal operating conditions.

Caution: Pay particular attention to the h.SP setting for max. product temperature. Do not set any higher than the product manufacturer maximum application temperature. Do not hesitate to ask your supervisor for the correct setting if any questions or concerns arise.

Watlow Series PM-12volt Temperature Controller

Operators Programming Sequence for 12 volt devices

Home Menu:

Procedure for programming the Series PM-12 volt Watlow Control.

Step 1: Connect all wires to Watlow control including RTD (temp sensor).

Step 2: Connect power to Watlow controller.

Step 3: Enter the Setup menu. (press both the **up and down** arrow keys for 6 seconds).
A1 will appear in the upper display and **SEt** will appear in the lower display.

Note:

*You will have to pass through the Operations menu to get to the Setup menu.
 Hold the up and down arrow keys simultaneously for 6 seconds to step through the menus.*

Step 4: Once **A1** is in the upper display, and **SEt** is in the lower display, you are in the Setup menu. If not, press the **infinity key** to return to the Home page and redo step 3.

Step 5: Press the **Advance key**. Use the **up or down** keys to change values.

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>	<u>Caution</u>
5-1	SEn Advance key	ro.1H	sensor type	Do not enter { rl.OH }
5-2	rt.L Advance key	2	RTD leads	
5-3	FIL Advance key	0.5	Filler type	
5-4	i.Er Advance key	off	error latching	
5-5	dEC Advance key	0	decimal	

Step 6: After pressing the **Advance key**, after parameter **dEC**, you will return to the parameter **.SEn**. Press the **infinity** key to return to the Setup menu. Display will show **{ Ai Set }**.

Step 7: Press either the **up or down** key to select the Loop submenu. **LOOP** will be in the upper display and **SEt** will be in the lower display. If this is shown, press the **advance key** to enter the Loop submenu. (once in the submenu, use the **up or down** key to change the parameter values).

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
7-1	h.Ag Advance key	on.of	heat algorithm
7-2	C.Ag Advance key	off	cool algorithm
7-3	UfA Advance key	off	user fail action
7-4	fAiL Advance key	off	input error failure
7-5	LodE Advance key	no	open loop detect enable
7-6	rP Advance key	off	ramp action
7-7	L.SP Advance key	0 degrees	low temperature set point(degrees)
7-8	h.SP Advance key	250 or 550	high temperature set point(degrees)
7-9	SP.Lo Advance key	-100.0	set point, low limit open loop
7-10	SP.Hi Advance key	100.0	set point, high limit open loop

Step 8: Pressing the **advance key** after parameter **SP.hi** will return you to the parameter **h.Ag**. Press the **infinity key** once to return to the setup menu.

Step 9: Use the **up or down** keys to select the output submenu. **otPt** will be in the upper display, and **SEt** will be in lower display. Press the **Advance key** to enter the submenu.

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
	(use the up or down key to change parameter values)		
9-1	Fn Advance key	heat	Function
9-2	o.tb Advance key	20.0	time base
9-3	O.LO Advance key	0%	low power scale
9-4	o.h1 Advance key	100%	high power scale

Step 10: Pressing the **advance key** after parameter **o.h1** will return you to parameter **Fn**. Press the **infinity key** to return to the output submenu.

Step 11: Use the **up or down** keys to select the global submenu **gLbL** will be in the upper display and **SEt** will be in the lower display. Press the **advance key** to enter the global menu.

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
11-1	C_F Advance key	F	display units
11-2	AC.LF Advance key	60	AC line frequency

Step 12: After pressing the **advance key** at parameter **AC.LF** will advance you back to parameter **C_F**. Press the **infinity key** once to return to the global submenu.

Step 13: Use the **up or down** keys to select the communication submenu. **Cor7** will be in the upper display and **SEt** will be in the lower display. Press the **advance key** to enter the communications submenu.

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
13-1	Ad.5 Advance key	1	Address Standard Bus

Step 14: Pressing the **advance key** on parameter **Ad.5** will advance you back to the same parameter, **ie.** you will still see parameter **Ad.5** displayed. Press the **infinity key** once to return to the communications sub menu.

Step 15: Press the **infinity key** to return to the Home page.

Step 16: From the Home page, press both the **up and down** keys for (3) seconds, **Ai** will appear in the upper display and **oPEr** will appear in the lower display.

Operations Page

Step 17: Once **Fli** is in the upper display and **oPEr** is in the lower display, you are at the Operations menu. If not, press the **infinity key** to return to the Home menu and redo step 16.

Step 18: Press the **up and down** keys until **LooP** is in the upper display and **oPEr** is in the lower display. Press the **advance key** to enter the **LooP** sub menu.

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
	(use the up or down keys to change values)		
18-1	C.r7 Advance key	auto	control mode
18-2	C.SP Advance key	75	closed loop setpoint

	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
18-3	id.5 Advance key	75 degree F.	Idle set point
18-4	h.hy Advance key	3.0 degree F.	Heat hysteresis reads 3 on display
18-5	o.SP Advance key	0.0%	Open loop set point

Step 19: Pressing the **advance key** at parameter **o.SP** will advance you back to parameter **C.r7**. Press the **infinity key** once to return you to operations Loop menu. Press the **infinity key** again to return you to the Home Page.

Step 20: Enter the Factory Page by pressing the **advance key** and **infinity keys** together and holding them for six (6) seconds. **CUSr** will be in the upper display and **FCty** will be in the lower display.

Factory Page

Step 21: Once **CUSr** is in the upper display and **FCty** is in the lower display, you are in the Factory menu. If not, press the **infinity key** to return to the Home Page and redo step 20.

Step 22: Press the advance key if **CUSr** is in the upper display and **FCty** is in the lower display. The upper display will now read **1** and the lower display will read **CUSr**. Press the **advance key** again.

Step 23: The upper display will read **AC.Pu** and the lower display will read **PAr**. If the upper display does not read this way, use the **up and down** keys to change the value. Once the value has been changed, press the **infinity key** once.

Step 24: The upper display will read **1** and the lower display will read **CUSr**. Use the **up or down** keys to change the upper display to read **2**, press the **advance key**.

Step 25: The upper display will read **AC.SP** and the lower display will read **PAr**. If the upper display reads differently, use the **up or down** keys to change it to **AC.SP**. Once complete, press the **infinity key** once.

Step 26: The upper display will read **2** and the lower display will read **CUSr**. Use the **up or down** keys to change the upper display to read **3**. Press the **advance key** once.

Step 27: The upper display will read some parameter or other, and the lower display will read **PAr**. Use the **up or down** keys to change the upper display to read **none**.

Once complete, press the **infinity key**.

Step 28: Repeat steps 26 and 27 for display values of 4 through 20, changing each parameter to **nonE**.

Note: *The upper display will show the previous value you changed. You must increment this value from 4 through 20!*

Step 29: When all 20 parameters are set, press the **infinity key** once to return you to the main Factory Page, **CUS** will be in the upper display and **FC** will be in the lower display.

Step 30: Use the **up or down** keys to move to the Lockout submenu. **LoC** will be in the upper display and **FC** will be in the lower display. Press the **advance key** to enter the Lockout submenu.


	<u>Parameter</u>	<u>Value</u>	<u>Description</u>
	(use the up or down keys to change parameter values)		
30-1	LoC.o	2	Lock Operations Page
	Advance key		
30-2	rLoC	1	Read Lockout Security
	Advance key		
30-3	SLoC	1	Set Lockout Security
	Advance key		

Step 31: Pressing the **advance key** at parameter **SLoC** will advance you to back to parameter **LoC.o**. Press the **infinity key** to return you to the Lockout submenu.

Step 32: Press the **infinity key** again to return you to the Home page.



Congratulations! Programming is Complete.

SCHEMATICS




NOTE: USE HOSE FOR CONNECTION TO PUMP USE STEEL TUBE FOR REST

ENGINE SPEED 2800 RPM
RELIEF 1000 PSI
HNO. PUMP 0.66 C.I.
PRODUCT PUMP MIR.2.2 C.I.
ALSES MIR. 14 C.I.



NOTE: ORIENTATE PUMP SWAGER SWITCH TO MAKE POWER CONNECTION ON, WHEN IN DOWN POSITION


9-PIN 37895, 37897 TRAILER PLUG AND SOCKET
SEE WAG-BOTTOM PRINT
9 PIN TO BE INSTALLED ON RIGHT SIDE OF BOX



<p>STEEP HFS CO INC NORTH BRANCH, MN 55056</p>		PROJECT:	12VDC FUEL OIL BURNER
<p>INV. NO:</p>		ASSY.:	BURNER VERTICAL D.K.'S
<p>W.T.:</p>		PART NAME:	WIRING
<p>W.T.:</p>		FILE NAME:	12VDCBURN-EZ
<p>W.T.:</p>		UPDATED:	
<p>W.T.:</p>		DMV BY:	
<p>W.T.:</p>		JOB DTY:	
<p>W.T.:</p>		JOB NO.:	
<p>W.T.:</p>		JOB DTY:	


NOTE: USED AS OF 3/4/90 75-125

Rev: 7-04 changed wand heat to high temp wire



HOSE ASS'Y
 12' - P/N 523092
 8' - P/N 523088

HOSE BOOM CABLE ASS'Y P/N 526115
 REV:10-02



OPTIONAL
 PUMP SAVER & EXACT FLOW







BOOM & HOSE HEAT

SHOP NOTES	MACHINE CODE
STANDARD SHOP TOLERANCE UNLESS OTHERWISE NOTED: ±1/16" & ±1°	LOCK FORMER: WIEDMANN: LARGE BRAKE:

ROUTING:	PROJECT:
CAGE CODE: 06447	ASS'Y: HEATED WAND & BOOM
DWN: 1/99	PART NAME: HEATED WAND & BOOM
REV: 7/04 - 1/05	FILE NAME: WAND & BOOM WIRING
INV NO:	WB-WD3P3
MAT'L: AS NOTED	QTY: 1
	INV AMT EA:
	JOB NO:
	JOB QTY:

SMGT
 STEPP MFG CO INC
 NORTH BRANCH, IN, 46056
 NOT TO BE REPRODUCED
 IN ANY FORM WITHOUT THE
 EXPRESSED WRITTEN PERMISSION
 OF STEPP MFG CO INC


REVISIONS			
REV.	DESCRIPTION	DATE	APPR
A01		6/16/2008	
B01		9/27/2008	



ITEM NO.	QTY.	PartNo	Description-1	Description-2
23	10	P100001619-095	PAN CROSS HD MACH SCREW	#6-32X0.5
22	8	P100001619-014	PAN CROSS HD MACH SCREW	#8-32X0.625X0.625-N
21	2	P100002858	4 POSITION TERMINAL BLOCK	30 AMP 600 VOLT MAX
20	1	P10002722	HOUR METER	SQUARE
19	2	P10002877	SEALED METAL ON-OFF-ON 1.5 AMP	3 TERMINAL
18	1	P10002876	CIRCUIT BREAKER 10 AMP	PANEL MOUNT
17	1	P10002009	PLUG NYLON	1/2 DIA X 1.25
16	1	P10002744	MASTER DISCONNECT SWITCH	1VR OPERATED ON-OFF SPST
15	1	P10002674	WIREWOUND RESISTOR	10 OHM .25 WATT
14	1	P10002630	RELAY HIGH CAPACITY	40A NC 20A 12V
13	1	P10002558	CONNECTOR STRAIN RELIEF 3/4	WATTEC 24604
12	1	P10002553	CPC CONNECTOR	4-PIN STD SQ FLANGE FEMALE
11	2	P10003540	WATLOW EZ PID TEMP CONTROLLER	12 VOLT
10	1	P10000179	BREAKER	20 AMP
9	1	P10002032	GROUNDING BAR	8 SCREW
8	1	P10000187	TERMINAL STRIP	8 X 30 AMP
7	2	P10000180	SP ST SWITCH ON-OFF	PLASTIC
6	1	P10000181	LIGHT	12 VOLT CALL FOR HEAT
5	1	M10003698	MOUNT RESISTOR 10A .25W	12 VOLT CALL FOR HEAT
4	1	M10003564	CPC 4 PIN COVER PLATE	TO MOUNT RESISTOR P10002674
3	1	M100001051-001	BOTTOM COVER PLATE	PANEL COVER PLATE
2	1	M10003229	INNER PANEL TOR 2 BURNER	CPC4 CON7 CPC4
1	1	M10003756	FRONT PANEL OJK BURNER & ELE WAND	STANDARD CONTROL BOX OJK BUREN/WAND PHOTO PLATE

REGENERATE AND COMPENSATE
 THIS DRAWING IS THE PROPERTY OF STEPP WFG CO INC
 IT IS TO BE USED ONLY FOR THE PROJECT AND QUANTITY SPECIFIED
 ANY REUSE OR MODIFICATION OF THIS DRAWING IS PROHIBITED
 STEPP WFG CO INC
 1700-2500
 1541
 DO NOT SCALE DRAWING
 SHEET 081

REV.	DESCRIPTION	DATE	APPR.
B01	RELEASED FOR PROTOTYPE	3/6/2010	



NOTE: USE BURNER CONFIGURATION 242-31A-J212

ITEM NO.	QTY.	PartNo	Description-1	Description-2
4	1	P10001539-002	ELL - ST - 90°	1/4 NPT
3	1	P10005132	F - 12 FUEL RETURN HEAD	BECKETT MODEL ADC DIESEL BURNER
2	1	P10005125	1.50 GPM BURNER NOZZLE	DIESEL BECKETT MODEL ADC BURNER
1	1	A10008215	BURNER BASE UNIT ASSY CPC	BURNER BASE UNIT ASSY

REV.	DESCRIPTION	DATE	APPR.
B01	RELEASED FOR PROTOTYPE	3/6/2010	

REV.	DESCRIPTION	DATE	APPR.
B01	RELEASED FOR PROTOTYPE	3/6/2010	


REV.	DESCRIPTION	DATE	APPR.
B01	RELEASED FOR PROTOTYPE	3/6/2010	

Burner Configuration Data Sheet




Stock Number	242 - 31A - J212	Where Used	
Flange Length	4	125 OJK	
Nozzle GPM	1.5		
Spray Angle	80°		
Head Size	F-12		
Run Type	INT		
Large Air Setting	0		
Small Air Setting	5		
Pressure	140		
Oil Inlet Location	BACK		
Oil Return	NO		

QTY-

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED HEREIN IS THE PROPERTY OF STEPP MFG. CO. AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS WITHOUT THE WRITTEN PERMISSION OF STEPP MFG. CO.

LOCK FORMER:	PROG #	TIP	SPEED	KEF	UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES FRACTIONAL: 1/16 ANGLE: MACH: 1/2° BEND: 1/16 DECIMAL: ±.010 THREE PLACE DECIMAL: ±.005	DRAWN: Loch	DATE: 7/22/2016	 STEPP MFG. CO. INC. 12325 River Rd. North Branch, Mn. 55066 Ph. 651-674-4891 Fax 651-674-4221
BRAKE:	PROG #	DE #	PUNCH #		THICKNESS:	CHECKED:	1/1/2006	
SMALL:						CREATED:		TITLE: BURNER ASSY FINAL
LARGE:						INTER-COMPANY DRAWING: YES/NO		PART NO. OJK 75 & 125
						MATERIAL TYPE:		SCALE: 1:2 WEIGHT: 21.95
						MATERIAL STOCK #		SHEET 2 OF 2
						REF #		REV
						DO NOT SCALE DRAWING		A10008105-005 B01+

REV.	DESCRIPTION	DATE	APPR
B03	UPDATED CTRL MOUNTING	7/30/2010	
B04	UPDATED FEET CONFIGS	8/17/2010	
B05	ADDED COVER BRACES, CHANGED CTRL MOUNTING	11/30/2010	



ITEM NO.	QTY.	PartNo	Description-1	Description-2
14	4	P10001601-001	BOLT	HEX - 1/4-20 X 3/4
13	2	P10001609-004	WASHER	FLAT 1/4
12	1	P10001600-001	NUT HEX	1/4-20NC
11	5	P10001608-004	WASHER	LOCK 1/4
10	3	P10001602-001	BOLT	HEX - 5/16 X 3/4
9	3	P10001608-005	WASHER	LOCK 5/16
8	3	P10001609-005	WASHER	FLAT 5/16
7	1	W10008378	Z602 ENGINE COVER W/LDM	Z602 FREE ENGINE PKG
6	1	M10008707	Z602 CTRL BOX MOUNT	Z602 FREE ENGINE ASSY
5	1	M10008687	ENG. COVER SUPPORT	SGS COVER REPAIR
4	1	M10008686	ENG. COVER SUPPORT	SGS ENG. REPAIR
3	1	M10008348	Z602 COVER MOUNT	Z602 FREE ENGINE PKG
2	1	M10003724	OIL FILL ACCESS COVER	Z482 ENGINE CABINET
1	1	A10008420-002	Z602 CTRL BOX PKG	Z602 BASE ENGINE ASSY
	-002/QTY.		Description-1	Description-2

PRELIMINARY AND CONFIDENTIAL
 THIS DRAWING IS THE PROPERTY OF STEPP MFG CO. INC.
 IT IS TO BE USED ONLY FOR THE PURPOSES SPECIFIED HEREIN.
 IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT THE WRITTEN PERMISSION OF STEPP MFG CO. INC.

STEPP MFG. CO. INC.
 10000 STEPP DRIVE
 WILSONVILLE, OR 97148
 TEL: 503.261.1111 FAX: 503.261.1112
 WWW.STEPPMFG.COM

DRAWING NO. 2602 CTRL & ALT PKG
 PART NO. A10008344-004
 REV. 1
 REF. 6000-1700-2500
 WEIGHT: 273.06
 SCALE: 1:8
 SHEET 1 OF 1

HEAT TRANSFER OIL MSDS

MATERIAL SAFETY DATA SHEET

SECTION 1	PRODUCT AND COMPANY IDENTIFICATION
------------------	---

PRODUCT

Product Name: TERESSTIC 460
Product Description: Base Oil and Additives
Product Code: 201560305570, 604496-00, 97P933
Intended Use: Circulating/gear oil

COMPANY IDENTIFICATION

Supplier: EXXON MOBIL CORPORATION
3225 GALLOWS RD.
FAIRFAX, VA. 22037 USA

24 Hour Health Emergency	609-737-4411
Transportation Emergency Phone	800-424-9300
Exxon Mobil Transportation No.	281-834-3296
MSDS Requests	713-613-3661
Product Technical Information	800-662-4525, 800-947-9147
MSDS Internet Address	http://www.exxon.com , http://www.mobil.com

SECTION 2	COMPOSITION / INFORMATION ON INGREDIENTS
------------------	---

No Reportable Hazardous Substance(s) or Complex Substance(s).

SECTION 3	HAZARDS IDENTIFICATION
------------------	-------------------------------

This material is not considered to be hazardous according to regulatory guidelines (see (M)SDS Section 15).

POTENTIAL HEALTH EFFECTS

Low order of toxicity. Excessive exposure may result in eye, skin, or respiratory irritation. High-pressure injection under skin may cause serious damage.

NFPA Hazard ID:	Health: 0	Flammability: 1	Reactivity: 0
HMIS Hazard ID:	Health: 0	Flammability: 1	Reactivity: 0

NOTE: This material should not be used for any other purpose than the intended use in Section 1 without expert advice. Health studies have shown that chemical exposure may cause potential human health risks which may vary from person to person.

SECTION 4	FIRST AID MEASURES
------------------	---------------------------

INHALATION

Remove from further exposure. For those providing assistance, avoid exposure to yourself or others. Use adequate respiratory protection. If respiratory irritation, dizziness, nausea, or unconsciousness occurs, seek immediate medical assistance. If breathing has stopped, assist ventilation with a mechanical device or use mouth-to-mouth resuscitation.

SKIN CONTACT

Wash contact areas with soap and water. If product is injected into or under the skin, or into any part of the body, regardless of the appearance of the wound or its size, the individual should be evaluated immediately by a physician as a surgical emergency. Even though initial symptoms from high pressure injection may be minimal or absent, early surgical treatment within the first few hours may significantly reduce the ultimate extent of injury.

EYE CONTACT

Flush thoroughly with water. If irritation occurs, get medical assistance.

INGESTION

First aid is normally not required. Seek medical attention if discomfort occurs.

SECTION 5	FIRE FIGHTING MEASURES
------------------	-------------------------------

EXTINGUISHING MEDIA

Appropriate Extinguishing Media: Use water fog, foam, dry chemical or carbon dioxide (CO2) to extinguish flames.

Inappropriate Extinguishing Media: Straight Streams of Water

FIRE FIGHTING

Fire Fighting Instructions: Evacuate area. Prevent runoff from fire control or dilution from entering streams, sewers, or drinking water supply. Firefighters should use standard protective equipment and in enclosed spaces, self-contained breathing apparatus (SCBA). Use water spray to cool fire exposed surfaces and to protect personnel.

Hazardous Combustion Products: Incomplete combustion products, Oxides of carbon, Smoke, Fume, Sulfur oxides, Aldehydes

FLAMMABILITY PROPERTIES

Flash Point [Method]: >288C (550F) [ASTM D-92]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Autoignition Temperature: N/D

SECTION 6	ACCIDENTAL RELEASE MEASURES
------------------	------------------------------------

NOTIFICATION PROCEDURES

In the event of a spill or accidental release, notify relevant authorities in accordance with all applicable regulations. In the event of a spill or accidental release, notify relevant authorities in accordance with all applicable regulations. US regulations require reporting releases of this material to the environment which exceed the applicable reportable quantity or oil spills which could reach any waterway including intermittent dry creeks. The National Response Center can be reached at (800)424-8802.

SPILL MANAGEMENT

Land Spill: Stop leak if you can do it without risk. Recover by pumping or with suitable absorbent.

Water Spill: Stop leak if you can do it without risk. Confine the spill immediately with booms. Warn other shipping. Remove from the surface by skimming or with suitable absorbents. Seek the advice of a specialist before using dispersants.

Water spill and land spill recommendations are based on the most likely spill scenario for this material; however, geographic conditions, wind, temperature, (and in the case of a water spill) wave and current direction and speed may greatly influence the appropriate action to be taken. For this reason, local experts should be consulted. Note: Local regulations may prescribe or limit action to be taken.

ENVIRONMENTAL PRECAUTIONS

Large Spills: Dike far ahead of liquid spill for later recovery and disposal. Prevent entry into waterways, sewers, basements or confined areas.

SECTION 7	HANDLING AND STORAGE
------------------	-----------------------------

HANDLING

Prevent small spills and leakage to avoid slip hazard.

Static Accumulator: This material is a static accumulator.

STORAGE

Do not store in open or unlabelled containers.

SECTION 8	EXPOSURE CONTROLS / PERSONAL PROTECTION
------------------	--

Exposure limits/standards for materials that can be formed when handling this product: When mists / aerosols can occur, the following are recommended: 5 mg/m³ - ACGIH TLV, 10 mg/m³ - ACGIH STEL, 5 mg/m³ - OSHA PEL.

NOTE: Limits/standards shown for guidance only. Follow applicable regulations.

ENGINEERING CONTROLS

The level of protection and types of controls necessary will vary depending upon potential exposure conditions. Control measures to consider:

No special requirements under ordinary conditions of use and with adequate ventilation.

PERSONAL PROTECTION

Personal protective equipment selections vary based on potential exposure conditions such as applications, handling practices, concentration and ventilation. Information on the selection of protective equipment for use with this material, as provided below, is based upon intended, normal usage.

Respiratory Protection: If engineering controls do not maintain airborne contaminant concentrations at a level which is adequate to protect worker health, an approved respirator may be appropriate. Respirator selection, use, and maintenance must be in accordance with regulatory requirements, if applicable. Types of respirators to be considered for this material include:

No special requirements under ordinary conditions of use and with adequate ventilation.

For high airborne concentrations, use an approved supplied-air respirator, operated in positive pressure mode. Supplied air respirators with an escape bottle may be appropriate when oxygen levels are inadequate, gas/vapor warning properties are poor, or if air purifying filter capacity/rating may be exceeded.

Hand Protection: Any specific glove information provided is based on published literature and glove manufacturer data. Work conditions can greatly affect glove durability; inspect and replace worn or damaged gloves. The types of gloves to be considered for this material include:

No protection is ordinarily required under normal conditions of use.

Eye Protection: If contact is likely, safety glasses with side shields are recommended.

Skin and Body Protection: Any specific clothing information provided is based on published literature or manufacturer data. The types of clothing to be considered for this material include:

No skin protection is ordinarily required under normal conditions of use. In accordance with good industrial hygiene practices, precautions should be taken to avoid skin contact.

Specific Hygiene Measures: Always observe good personal hygiene measures, such as washing after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants. Discard contaminated clothing and footwear that cannot be cleaned. Practice good housekeeping.

ENVIRONMENTAL CONTROLS

See Sections 6, 7, 12, 13.

SECTION 9

PHYSICAL AND CHEMICAL PROPERTIES

Typical physical and chemical properties are given below. Consult the Supplier in Section 1 for additional data.

GENERAL INFORMATION

Physical State: Liquid

Color: Brown

Odor: Characteristic

Odor Threshold: N/D

IMPORTANT HEALTH, SAFETY, AND ENVIRONMENTAL INFORMATION

Relative Density (at 15 C): 0.903

Flash Point [Method]: >288C (550F) [ASTM D-92]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Autoignition Temperature: N/D

Boiling Point / Range: > 316C (600F)

Vapor Density (Air = 1): > 2 at 101 kPa

Vapor Pressure: < 0.013 kPa (0.1 mm Hg) at 20 C

Evaporation Rate (n-butyl acetate = 1): N/D

pH: N/A

Log Pow (n-Octanol/Water Partition Coefficient): > 3.5

Solubility in Water: Negligible

Viscosity: 460 cSt (460 mm²/sec) at 40 C | 30.5 cSt (30.5 mm²/sec) at 100C

Oxidizing Properties: See Sections 3, 15, 16.

OTHER INFORMATION

Freezing Point: N/D

Melting Point: N/A

Pour Point: -6°C (21°F)

DMSO Extract (mineral oil only), IP-346: < 3 %wt

SECTION 10	STABILITY AND REACTIVITY
-------------------	---------------------------------

STABILITY: Material is stable under normal conditions.

CONDITIONS TO AVOID: Excessive heat. High energy sources of ignition.

MATERIALS TO AVOID: Strong oxidizers

HAZARDOUS DECOMPOSITION PRODUCTS: Material does not decompose at ambient temperatures.

HAZARDOUS POLYMERIZATION: Will not occur.

SECTION 11	TOXICOLOGICAL INFORMATION
-------------------	----------------------------------

ACUTE TOXICITY

<u>Route of Exposure</u>	<u>Conclusion / Remarks</u>
Inhalation	
Toxicity (Rat): LC50 > 5000 mg/m ³	Minimally Toxic. Based on test data for structurally similar materials.
Irritation: Data available.	Negligible hazard at ambient/normal handling temperatures. Based on assessment of the components.
Ingestion	
Toxicity (Rat): LD50 > 2000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Skin	
Toxicity (Rabbit): LD50 > 2000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Irritation (Rabbit): Data available.	Negligible irritation to skin at ambient temperatures. Based on test data for structurally similar materials.
Eye	
Irritation (Rabbit): Data available.	May cause mild, short-lasting discomfort to eyes. Based on test data for structurally similar materials.

CHRONIC/OTHER EFFECTS

For the product itself:

Repeated and/or prolonged exposure may cause irritation to the skin, eyes, or respiratory tract.

Contains:

Base oil severely refined: Not carcinogenic in animal studies. Representative material passes IP-346, Modified Ames test, and/or other screening tests. Dermal and inhalation studies showed minimal effects; lung non-specific infiltration of immune cells, oil deposition and minimal granuloma formation. Not sensitizing in test animals.

Additional information is available by request.

The following ingredients are cited on the lists below: None.

--REGULATORY LISTS SEARCHED--

1 = NTP CARC

3 = IARC 1

5 = IARC 2B

2 = NTP SUS

4 = IARC 2A

6 = OSHA CARC

SECTION 12**ECOLOGICAL INFORMATION**

The information given is based on data available for the material, the components of the material, and similar materials.

ECOTOXICITY

Material -- Not expected to be harmful to aquatic organisms.

MOBILITY

Base oil component -- Low solubility and floats and is expected to migrate from water to the land. Expected to partition to sediment and wastewater solids.

PERSISTENCE AND DEGRADABILITY**Biodegradation:**

Base oil component -- Expected to be inherently biodegradable

BIOACCUMULATION POTENTIAL

Base oil component -- Has the potential to bioaccumulate, however metabolism or physical properties may reduce the bioconcentration or limit bioavailability.

SECTION 13**DISPOSAL CONSIDERATIONS**

Disposal recommendations based on material as supplied. Disposal must be in accordance with current applicable laws and regulations, and material characteristics at time of disposal.

DISPOSAL RECOMMENDATIONS

Product is suitable for burning in an enclosed controlled burner for fuel value or disposal by supervised incineration at very high temperatures to prevent formation of undesirable combustion products.

REGULATORY DISPOSAL INFORMATION

RCRA Information: The unused product, in our opinion, is not specifically listed by the EPA as a hazardous waste (40 CFR, Part 261D), nor is it formulated to contain materials which are listed as hazardous wastes. It does not exhibit the hazardous characteristics of ignitability, corrosivity or reactivity and is not formulated with contaminants as determined by the Toxicity Characteristic Leaching Procedure (TCLP). However, used product may be regulated.

Empty Container Warning Empty Container Warning (where applicable): Empty containers may contain residue and can be dangerous. Do not attempt to refill or clean containers without proper instructions. Empty drums should be completely drained and safely stored until appropriately reconditioned or disposed. Empty containers should be taken for recycling, recovery, or disposal through suitably qualified or licensed contractor and in accordance with governmental regulations. **DO NOT PRESSURISE, CUT, WELD, BRAZE, SOLDER, DRILL, GRIND, OR EXPOSE SUCH CONTAINERS TO HEAT, FLAME, SPARKS, STATIC ELECTRICITY, OR OTHER SOURCES OF IGNITION. THEY MAY EXPLODE AND CAUSE INJURY OR DEATH.**

SECTION 14	TRANSPORT INFORMATION
-------------------	------------------------------

LAND (DOT) : Not Regulated for Land Transport

LAND (TDG) : Not Regulated for Land Transport

SEA (IMDG) : Not Regulated for Sea Transport according to IMDG-Code

AIR (IATA) : Not Regulated for Air Transport

SECTION 15	REGULATORY INFORMATION
-------------------	-------------------------------

OSHA HAZARD COMMUNICATION STANDARD: When used for its intended purposes, this material is not classified as hazardous in accordance with OSHA 29 CFR 1910.1200.

NATIONAL CHEMICAL INVENTORY LISTING: KECI, EINECS, IECSC, PICCS, TSCA, ENCS, AICS, DSL

EPCRA: This material contains no extremely hazardous substances.

SARA (311/312) REPORTABLE HAZARD CATEGORIES: None.

SARA (313) TOXIC RELEASE INVENTORY: This material contains no chemicals subject to the supplier notification requirements of the SARA 313 Toxic Release Program.

The Following Ingredients are Cited on the Lists Below:

Chemical Name	CAS Number	List Citations
DIPHENYLAMINE	122-39-4	5
XYLENES	1330-20-7	5

--REGULATORY LISTS SEARCHED--

- | | | | |
|---------------|------------------|-------------------|-------------|
| 1 = ACGIH ALL | 6 = TSCA 5a2 | 11 = CA P65 REPRO | 16 = MN RTK |
| 2 = ACGIH A1 | 7 = TSCA 5e | 12 = CA RTK | 17 = NJ RTK |
| 3 = ACGIH A2 | 8 = TSCA 6 | 13 = IL RTK | 18 = PA RTK |
| 4 = OSHA Z | 9 = TSCA 12b | 14 = LA RTK | 19 = RI RTK |
| 5 = TSCA 4 | 10 = CA P65 CARC | 15 = MI 293 | |

Code key: CARC=Carcinogen; REPRO=Reproductive

N/D = Not determined, N/A = Not applicable

THIS SAFETY DATA SHEET CONTAINS THE FOLLOWING REVISIONS:

No revision information is available.

The information and recommendations contained herein are, to the best of ExxonMobil's knowledge and belief, accurate and reliable as of the date issued. You can contact ExxonMobil to insure that this document is the most current available from ExxonMobil. The information and recommendations are offered for the user's consideration and examination. It is the user's responsibility to satisfy itself that the product is suitable for the intended use. If buyer repackages this product, it is the user's responsibility to insure proper health, safety and other necessary information is included with and/or on the container. Appropriate warnings and safe-handling procedures should be provided to handlers and users. Alteration of this document is strictly prohibited. Except to the extent required by law, re-publication or retransmission of this document, in whole or in part, is not permitted. The term, "ExxonMobil" is used for convenience, and may include any one or more of ExxonMobil Chemical Company, Exxon Mobil Corporation, or any affiliates in which they directly or indirectly hold any interest.

Internal Use Only

MHC: 0, 0, 0, 0, 0, 0

PPEC: A

DGN: 2026174XUS (548955)

Copyright 2002 Exxon Mobil Corporation, All rights reserved

HYDRAULIC OIL MSDS

MATERIAL SAFETY DATA SHEET

SECTION 1	PRODUCT AND COMPANY IDENTIFICATION
------------------	---

PRODUCT

Product Name: UNIVIS N 32
Product Description: Base Oil and Additives
Product Code: 8259
Intended Use: Hydraulic fluid

COMPANY IDENTIFICATION

Supplier: Canada Imperial Oil Limited, An Affiliate of Exxon Mobil Corporation
P.O. Box 4029, Station A
Calgary, ALBERTA. T2P 3M9 Canada

24 Hour Health Emergency 519-339-2145
Transportation Emergency Phone 519-339-2145
Supplier General Contact 1-800-567-3776

SECTION 2	COMPOSITION / INFORMATION ON INGREDIENTS
------------------	---

Reportable Hazardous Substance(s) or Complex Substance(s)

Name	CAS#	Concentration*
HYDROTREATED LIGHT NAPHTHENIC DISTILLATE (PETROLEUM)	64742-53-6	20 - 30%

* All concentrations are percent by weight unless material is a gas. Gas concentrations are in percent by volume.

SECTION 3	HAZARDS IDENTIFICATION
------------------	-------------------------------

This material is not considered to be hazardous according to regulatory guidelines (see (M)SDS Section 15).

POTENTIAL HEALTH EFFECTS

Low order of toxicity. Excessive exposure may result in eye, skin, or respiratory irritation. High-pressure injection under skin may cause serious damage.

NFPA Hazard ID: Health: 0 Flammability: 1 Reactivity: 0
HMIS Hazard ID: Health: 0 Flammability: 1 Reactivity: 0

NOTE: This material should not be used for any other purpose than the intended use in Section 1 without expert advice. Health studies have shown that chemical exposure may cause potential human health risks which may vary from person to person.

SECTION 4	FIRST AID MEASURES
------------------	---------------------------

INHALATION

Remove from further exposure. For those providing assistance, avoid exposure to yourself or others. Use adequate respiratory protection. If respiratory irritation, dizziness, nausea, or unconsciousness occurs, seek immediate medical assistance. If breathing has stopped, assist ventilation with a mechanical device or use mouth-to-mouth resuscitation.

SKIN CONTACT

Wash contact areas with soap and water. If product is injected into or under the skin, or into any part of the body, regardless of the appearance of the wound or its size, the individual should be evaluated immediately by a physician as a surgical emergency. Even though initial symptoms from high pressure injection may be minimal or absent, early surgical treatment within the first few hours may significantly reduce the ultimate extent of injury.

EYE CONTACT

Flush thoroughly with water. If irritation occurs, get medical assistance.

INGESTION

First aid is normally not required. Seek medical attention if discomfort occurs.

SECTION 5	FIRE FIGHTING MEASURES
------------------	-------------------------------

EXTINGUISHING MEDIA

Appropriate Extinguishing Media: Use water fog, foam, dry chemical or carbon dioxide (CO₂) to extinguish flames.

Inappropriate Extinguishing Media: Straight Streams of Water

FIRE FIGHTING

Fire Fighting Instructions: Evacuate area. Prevent runoff from fire control or dilution from entering streams, sewers, or drinking water supply. Firefighters should use standard protective equipment and in enclosed spaces, self-contained breathing apparatus (SCBA). Use water spray to cool fire exposed surfaces and to protect personnel.

Unusual Fire Hazards: Pressurized mists may form a flammable mixture.

Hazardous Combustion Products: Smoke, Fume, Sulfur oxides, Aldehydes, Oxides of carbon, Incomplete combustion products

FLAMMABILITY PROPERTIES

Flash Point [Method]: 165C (329F) [ASTM D-93]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Autoignition Temperature: N/D

SECTION 6**ACCIDENTAL RELEASE MEASURES****NOTIFICATION PROCEDURES**

In the event of a spill or accidental release, notify relevant authorities in accordance with all applicable regulations. U.S. regulations require reporting releases of this material to the environment which exceed the reportable quantity or oil spills which could reach any waterway including intermittent dry creeks. The National Response Center can be reached at (800)424-8802.

SPILL MANAGEMENT

Land Spill: Stop leak if you can do it without risk. Recover by pumping or with suitable absorbent.

Water Spill: Stop leak if you can do it without risk. Confine the spill immediately with booms. Warn other shipping. Remove from the surface by skimming or with suitable absorbents. Seek the advice of a specialist before using dispersants.

Water spill and land spill recommendations are based on the most likely spill scenario for this material; however, geographic conditions, wind, temperature, (and in the case of a water spill) wave and current direction and speed may greatly influence the appropriate action to be taken. For this reason, local experts should be consulted. Note: Local regulations may prescribe or limit action to be taken.

ENVIRONMENTAL PRECAUTIONS

Large Spills: Dike far ahead of liquid spill for later recovery and disposal. Prevent entry into waterways, sewers, basements or confined areas.

SECTION 7**HANDLING AND STORAGE****HANDLING**

Prevent small spills and leakage to avoid slip hazard.

Static Accumulator: This material is a static accumulator.

STORAGE

Do not store in open or unlabelled containers.

SECTION 8**EXPOSURE CONTROLS / PERSONAL PROTECTION**

Exposure limits/standards for materials that can be formed when handling this product: When mists / aerosols can occur, the following are recommended: 5 mg/m³ - ACGIH TLV, 10 mg/m³ - ACGIH STEL, 5 mg/m³ - OSHA PEL.

NOTE: Limits/standards shown for guidance only. Follow applicable regulations.

ENGINEERING CONTROLS

The level of protection and types of controls necessary will vary depending upon potential exposure conditions. Control measures to consider:

No special requirements under ordinary conditions of use and with adequate ventilation.

PERSONAL PROTECTION

Personal protective equipment selections vary based on potential exposure conditions such as applications, handling practices, concentration and ventilation. Information on the selection of protective equipment for use with this material, as provided below, is based upon intended, normal usage.

Respiratory Protection: If engineering controls do not maintain airborne contaminant concentrations at a level which is adequate to protect worker health, an approved respirator may be appropriate. Respirator selection, use, and maintenance must be in accordance with regulatory requirements, if applicable. Types of respirators to be considered for this material include:

No special requirements under ordinary conditions of use and with adequate ventilation. For high airborne concentrations, use an approved supplied-air respirator, operated in positive pressure mode. Supplied air respirators with an escape bottle may be appropriate when oxygen levels are inadequate, gas/vapor warning properties are poor, or if air purifying filter capacity/rating may be exceeded.

Hand Protection: Any specific glove information provided is based on published literature and glove manufacturer data. Work conditions can greatly effect glove durability; inspect and replace worn or damaged gloves. The types of gloves to be considered for this material include:

No protection is ordinarily required under normal conditions of use.

Eye Protection: If contact is likely, safety glasses with side shields are recommended.

Skin and Body Protection: Any specific clothing information provided is based on published literature or manufacturer data. The types of clothing to be considered for this material include:

No skin protection is ordinarily required under normal conditions of use. In accordance with good industrial hygiene practices, precautions should be taken to avoid skin contact.

Specific Hygiene Measures: Always observe good personal hygiene measures, such as washing after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants. Discard contaminated clothing and footwear that cannot be cleaned. Practice good housekeeping.

ENVIRONMENTAL CONTROLS

See Sections 6, 7, 12, 13.

SECTION 9	PHYSICAL AND CHEMICAL PROPERTIES
------------------	---

Typical physical and chemical properties are given below. Consult the Supplier in Section 1 for additional data.

GENERAL INFORMATION

Physical State: Liquid

Color: Yellow

Odor: Characteristic

Odor Threshold: N/D

IMPORTANT HEALTH, SAFETY, AND ENVIRONMENTAL INFORMATION

Relative Density (at 15 C): 0.87

Flash Point [Method]: 165C (329F) [ASTM D-93]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Autoignition Temperature: N/D

Boiling Point / Range: 229C (444F) - 512C (954F)

Vapor Density (Air = 1): N/D

Vapor Pressure: [N/D at 40 °C] | < 1 kPa (7.5 mm Hg) at 38C

Evaporation Rate (n-butyl acetate = 1): < 0.1

pH: N/A

Log Pow (n-Octanol/Water Partition Coefficient): > 3.5

Solubility in Water: Negligible

Viscosity: 32 cSt (32 mm²/sec) at 40 C

Oxidizing Properties: See Sections 3, 15, 16.

OTHER INFORMATION**Freezing Point:** N/D**Melting Point:** N/A**Pour Point:** -48°C (-54°F)**DMSO Extract (mineral oil only), IP-346:** < 3 %wt

SECTION 10	STABILITY AND REACTIVITY
-------------------	---------------------------------

STABILITY: Material is stable under normal conditions.**CONDITIONS TO AVOID:** Excessive heat. High energy sources of ignition.**MATERIALS TO AVOID:** Strong oxidizers**HAZARDOUS DECOMPOSITION PRODUCTS:** Material does not decompose at ambient temperatures.**HAZARDOUS POLYMERIZATION:** Will not occur.

SECTION 11	TOXICOLOGICAL INFORMATION
-------------------	----------------------------------

ACUTE TOXICITY

<u>Route of Exposure</u>	<u>Conclusion / Remarks</u>
Inhalation	
Toxicity (Rat): LC50 > 5000 mg/m ³	Minimally Toxic. Based on assessment of the components.
Irritation: No end point data.	Negligible hazard at ambient/normal handling temperatures. Based on assessment of the components.
Ingestion	
Toxicity (Rat): LD50 > 2000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Skin	
Toxicity (Rabbit): LD50 > 2000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Irritation (Rabbit): Data available.	Negligible irritation to skin at ambient temperatures. Based on assessment of the components.
Eye	
Irritation (Rabbit): Data available.	May cause mild, short-lasting discomfort to eyes. Based on assessment of the components.

CHRONIC/OTHER EFFECTS**Contains:**

Base oil severely refined: Not carcinogenic in animal studies. Representative material passes IP-346, Modified Ames test, and/or other screening tests. Dermal and inhalation studies showed minimal effects; lung non-specific infiltration of immune cells, oil deposition and minimal granuloma formation. Not sensitizing in test animals.

Additional information is available by request.

The following ingredients are cited on the lists below: None.

--REGULATORY LISTS SEARCHED--

1 = NTP CARC

3 = IARC 1

5 = IARC 2B

2 = NTP SUS

4 = IARC 2A

6 = OSHA CARC

SECTION 12**ECOLOGICAL INFORMATION**

The information given is based on data available for the material, the components of the material, and similar materials.

ECOTOXICITY

Material -- Not expected to be harmful to aquatic organisms.

MOBILITY

Base oil component -- Low solubility and floats and is expected to migrate from water to the land. Expected to partition to sediment and wastewater solids.

PERSISTENCE AND DEGRADABILITY**Biodegradation:**

Base oil component -- Expected to be inherently biodegradable

BIOACCUMULATION POTENTIAL

Base oil component -- Has the potential to bioaccumulate, however metabolism or physical properties may reduce the bioconcentration or limit bioavailability.

SECTION 13**DISPOSAL CONSIDERATIONS**

Disposal recommendations based on material as supplied. Disposal must be in accordance with current applicable laws and regulations, and material characteristics at time of disposal.

DISPOSAL RECOMMENDATIONS

Product is suitable for burning in an enclosed controlled burner for fuel value or disposal by supervised incineration at very high temperatures to prevent formation of undesirable combustion products.

REGULATORY DISPOSAL INFORMATION

RCRA Information: The unused product, in our opinion, is not specifically listed by the EPA as a hazardous waste (40 CFR, Part 261D), nor is it formulated to contain materials which are listed as hazardous wastes. It does not exhibit the hazardous characteristics of ignitability, corrosivity or reactivity and is not formulated with contaminants as determined by the Toxicity Characteristic Leaching Procedure (TCLP). However, used product may be regulated.

Empty Container Warning PRECAUTIONARY LABEL TEXT: Empty containers may retain residue and can be dangerous. DO NOT PRESSURIZE, CUT, WELD, BRAZE, SOLDER, DRILL, GRIND OR EXPOSE SUCH CONTAINERS TO HEAT, FLAME, SPARKS, STATIC ELECTRICITY, OR OTHER SOURCES OF IGNITION; THEY MAY EXPLODE AND CAUSE INJURY OR DEATH. Do not attempt to refill or clean container since residue is difficult to remove. Empty drums should be completely drained, properly bunged and promptly returned to a drum reconditioner. All containers should be disposed of in an environmentally safe manner and in accordance with governmental regulations.

SECTION 14	TRANSPORT INFORMATION
-------------------	------------------------------

LAND (DOT) : Not Regulated for Land Transport

LAND (TDG) : Not Regulated for Land Transport

SEA (IMDG) : Not Regulated for Sea Transport according to IMDG-Code

AIR (IATA) : Not Regulated for Air Transport

SECTION 15	REGULATORY INFORMATION
-------------------	-------------------------------

OSHA HAZARD COMMUNICATION STANDARD: When used for its intended purposes, this material is not classified as hazardous in accordance with OSHA 29 CFR 1910.1200.

NATIONAL CHEMICAL INVENTORY LISTING: DSL, TSCA

EPCRA: This material contains no extremely hazardous substances.

SARA (311/312) REPORTABLE HAZARD CATEGORIES: Delayed Health.

SARA (313) TOXIC RELEASE INVENTORY: This material contains no chemicals subject to the supplier notification requirements of the SARA 313 Toxic Release Program.

The Following Ingredients are Cited on the Lists Below:*

Chemical Name	CAS Number	List Citations
HYDROTREATED LIGHT NAPHTHENIC DISTILLATE (PETROLEUM)	64742-53-6	13, 17, 18
PHOSPHORODITHOIC ACID, O,O-DI C1-14-ALKYL ESTERS, ZINC SALTS (2:1) (ZDDP)	68649-42-3	15

--REGULATORY LISTS SEARCHED--

- | | | | |
|---------------|------------------|-------------------|-------------|
| 1 = ACGIH ALL | 6 = TSCA 5a2 | 11 = CA P65 REPRO | 16 = MN RTK |
| 2 = ACGIH A1 | 7 = TSCA 5e | 12 = CA RTK | 17 = NJ RTK |
| 3 = ACGIH A2 | 8 = TSCA 6 | 13 = IL RTK | 18 = PA RTK |
| 4 = OSHA Z | 9 = TSCA 12b | 14 = LA RTK | 19 = RI RTK |
| 5 = TSCA 4 | 10 = CA P65 CARC | 15 = MI 293 | |

Code key: CARC=Carcinogen; REPRO=Reproductive

* EPA recently added new chemical substances to its TSCA Section 4 test rules. Please contact the supplier to confirm whether the ingredients in this product currently appear on a TSCA 4 or TSCA 12b list.

N/D = Not determined, N/A = Not applicable

THIS SAFETY DATA SHEET CONTAINS THE FOLLOWING REVISIONS:

No revision information is available.

The information and recommendations contained herein are, to the best of ExxonMobil's knowledge and belief, accurate and reliable as of the date issued. You can contact ExxonMobil to insure that this document is the most current available from ExxonMobil. The information and recommendations are offered for the user's consideration and examination. It is the user's responsibility to satisfy itself that the product is suitable for the intended use. If buyer repackages this product, it is the user's responsibility to insure proper health, safety and other necessary information is included with and/or on the container. Appropriate warnings and safe-handling procedures should be provided to handlers and users. Alteration of this document is strictly prohibited. Except to the extent required by law, re-publication or retransmission of this document, in whole or in part, is not permitted. The term, "ExxonMobil" is used for convenience, and may include any one or more of ExxonMobil Chemical Company, Exxon Mobil Corporation, or any affiliates in which they directly or indirectly hold any interest.

Internal Use Only

MHC: 0, 0, 0, 0, 0, 0

PPEC: A

DGN: 5007202 (1012936)

Copyright 2002 Exxon Mobil Corporation, All rights reserved

TIRE INFORMATION

ENGINE MANUAL
